H&H Consulting Engineers Pty Ltd (trading as Henry & Hymas)

ABN 77 091 243 355 ACN 091 243 355

Address Level 5 79 Victoria Avenue Chatswood New South Wales 2067

Telephone +61 2 9417 8400

Facsimile +61 2 9417 8337

email@hhconsult.com.au

www.henryandhymas.com.au



31 August 2017

Frasers Property Australia C/- Property Development Solutions (Aust) Pty Ltd Level 1, 63 York St SYDNEY NSW 2000

Attention: Ms Vanessa English

Dear Vanessa,

RE: **EASTERN CREEK RETAIL CENTRE STAGE 1** ROOTY HILL ROAD SOUTH, EASTERN CREEK STORMWATER ISSUES AND DESIGN REPORT FOR DEVELOPMENT APPLICATION

PROJECT OVERVIEW

It is proposed to develop an existing Greenfield site of approximately 4.2 hectares to a mixed use development consisting of commercial and retail areas. This site is part of a larger retail and commercial precinct that will be known as the Eastern Creek Quarter (ECQ). It is proposed that the overall precinct will be developed in three separate stages. This development application (DA) will focus on stage 1 and its location is shown on figure 1 below.

This report has been prepared to support State Significant Development Application SSD 8588 for the detailed design and construction of a convenience retail shopping centre, medical centre, gym and associated car parking on Lot 2, Rooty Hill Road South, Eastern Creek. The assessment undertaken in this report has been prepared to address the following Secretary's Environmental Assessment Requirements (dated 26 July 2017) and the relevant conditions of consent under Concept Approval SSD 5175:

The site lies directly to the east of Rooty Hill Road South. At the time of this submission, we have shown the surrounding infrastructure on our plans as being in place. In reality, this has not been constructed yet, but have had to assume that the site will be connecting into these roads, channels, stormwater and quantity/quality basins. The status of these surrounding works will be explained in detail in later sections of this report.

The existing topography of the site is that the majority falls in an easterly direction at approximately 5%. Runoff from the site currently is directed overland to two sets of culverts located at the far eastern edge of the overall precinct site. These culverts discharge to the east and eventually to Eastern Creek. The proposed stormwater from the developed stage 1 site will ultimately follow this same path to Eastern Creek.

In terms of stormwater measures, it is proposed to direct the site's stormwater to the previously designed stormwater infrastructure within the proposed subdivision access road. This downstream stormwater and road infrastructure design includes combined On Site Detention (OSD) and Water Quality (WQ) basins to treat the entire ECQ 3 precinct, including this stage 1 development. As such, there is no requirement for full WQ and OSD measures on this site. However, we have designed the site stormwater Global-Mark.com.au®





system to provide pit inlet filters in all surface inlet pits as well as water conservation measures. The details of the measures will be further explained in later sections of this report.



Figure 1: Location of proposed site

SURROUNDING ROADS AND STORMWATER INFRASTRUCTURE

As mentioned above, the site is 1 stage of a 3 stage commercial/retail precinct. This overall precinct area requires the installation of appropriate access roads and downstream stormwater infrastructure for the site to connect in to. In addition to this, there are proposed upgrades and amplifications of the adjoining Rooty Hill Road/Cable Place intersection and Rooty Hill Road South/Great Western Highway intersection.

The original subdivision access road and stormwater infrastructure design for the precinct area was carried out and approved under the following application and development consent.

- Application no. SSD 5175 MOD 1
- Applicant: Western Sydney Parklands Trust
- Consent Authority: Minister for Planning
- Approval date: 28th April 2016

The civil infrastructure design and drawings that formed part of this consent have been used as the basis for the site's connecting stormwater and access. The original civil infrastructure drawings



were completed by Costin Roe Engineers with both water quality and OSD requirements for the northern precinct lots catered for in their design. For information purposes, we have included the overall site works plan for these infrastructure works as an appendix to this report – C012693.00-DA15 (B). A full and detailed analysis of the proposed precinct water quality and OSD controls are provided in the Costin Roe Engineering report - Civil engineering report: amendment to state significant development 5175-2012 (rev B – 2015).

It should be noted that the above development consent contained conditions relating to the subdivision road and stormwater infrastructure. At the time of this report, Henry and Hymas have not been responsible for any formal updates/changes to this design.

The Rooty Hill Road South/Cable Place amplifications are shown as a background to the site layout plans. These are currently being documented to a standard to obtain a Works Authorisation Deed (WAD) with RMS. As such, this layout is provided on our drawings for information purposes only. The RMS approved concept plans for these surrounding road works are attached as an appendix to this report.

STORMWATER STRATEGY

As discussed earlier, the site has an area of approximately 4.2 hectares and currently drains in an easterly direction towards two culverts that pass under the M7 motorway. The site stormwater system has been designed to connect to a set of twin culverts that are located underneath the low point of the future access road. Given that the proposed invert levels of this culvert are RL39.60 and that the site floor level is RL44.30, there is ample depth to be able to pipe the entirety of the site stormwater.

As explained above, there is a precinct wide strategy proposed to deal with this site's stormwater quantity controls. As such, no OSD is proposed for this site.

In accordance with Blacktown City Council's Engineering Guideline (2005), the piped stormwater system has been designed to accommodate the 1:20 ARI peak flows. The site grading has been designed in such a way that any emergency overflow up to the 100ARI peak storm will pass through the site and to the external site access road without adversely impacting the site floor level.

Drawings 17570_DA_C101-C104 detail the site grading and stormwater layout/strategy. All site stormwater longitudinal sections are shown on drawings 17570_DA_C210-C213. A general stormwater maintenance strategy for the various stormwater elements on the site is provided as an attachment to this report.

The site drainage system has been designed using the DRAINS modelling software. The DRAINS model prepared and submitted for the site stormwater system is;

• 17570 DRAINS2.drn



DRAINS MODELLING DATA

For the above mentioned model, the IFD data used for the rainfall generation is;

Table 1

	2ARI	50ARI		
1hr	30.6(mm/hr)	56.4(mm/hr)	G	0.01
12hr	6.67(mm/hr)	12.8(mm/hr)	F2	4.30
72hr	2(mm/hr)	4.3(mm/hr)	F50	15.81

The standard parameters used in the DRAINS model are as follows;

Table 2

Description	Value
Model for Design and Analysis Run	Rational Method
Rational Method Procedure	ARR87
Soil Type - Normal	3.0
Paved (Impervious) Are Depression Storage	1mm
Supplementary Area Depression Storage	1mm
Grassed (Pervious) Area Depression Storage	5mm (15mm for
, , ,	pre-dev)
Antecedent Moisture Condition (ARI = 1-5 years)	2.5
Antecedent Moisture Condition (ARI = 10-20 years)	3.0
Antecedent Moisture Condition (ARI = 50-100 years)	3.5
Sag Pit Blocking Factor	0.5
On Grade Pit Blocking Factor	0.2

WATER QUALITY STRATEGY

In accordance with the precinct wide water strategy proposed in the Costing Roe Engineering Report and Plans, tertiary treatment will be provided within the communal basin downstream of the site. The strategy proposed by Costing Roe assumes that only primary treatment for the on-lot stormwater system is required. As such, we have nominated that all surface inlet pits within the site are to be fitted with Enviropod pit baskets. In areas of vehicular traffic, oilsorbs are to be fitted within the baskets. Drawing 17570_DA_C200 indicates all the pits that are to be fitted with the Enviropods.

A generic operational and maintenance manual for the enviropod pit basket is attached as an appendix to this report.

In accordance with Blacktown Council's Development Control Plan, Part J, the site must meet the following pollutant reduction targets.



Table 3

Pollutant	% post development reduction target		
Gross Pollutants	90		
Total Suspended Solids	85		
Total Phosphorous	65		
Total Nitrogen	45		
Total Hydrocarbons	90		

Refer to the precinct wide Engineering report by Costin Roe for details on how these targets will be met for all lots within the precinct.

WATER CONSERVATION

To assist with water conservation, it is proposed that a 200kL rainwater tank be incorporated to meet a significant portion of the non-potable demands. As the original development application of this site pre-dates Council's water quality conservation policy, we have not designed the tank to supply 80% of the re-use demand. We have used a practical roof catchment area and rainwater tank size based on the building and roof layout.

The following non-potable demands were used in order to calculate the proposed rainwater tank effectiveness.

- Toilet Flushing: 56 toilets @0.1kL/day = <u>5.6kL/day</u>. Number of toilets based on the B.C.A. report for the development.
- Irrigation: 5000m² of irrigable area (area provided by landscape architect) @ 0.3kL/m²/yr (drip): = 1500kL/yr.

These demands were used in a MUSIC model water balance to determine the re-use demand met based on a roof catchment area of 8578m². For a 200kL tank, the effective storage is 160kL which allows for a 20% loss due to anaerobic zones.

Refer to catchment plan 17570_DA_C251 for detailed analysis of the rainwater re-use strategy. Based on a catchment area of 8578m², the 200kL rainwater tank will meet 64% of the non-potable demand for the site.

The modelling procedure was undertaken using the MUSIC software program.

The MUSIC model provided for Council assessment for this site is;

17570 – RW tank sizing 200Kl – final for DA.SQZ

For the MUSIC model itself, we have used the following rainfall station and time period data.

Table 4

Rainfall Station	Modelling period	Annual rainfall(mm)
067035 Liverpool (Whitlam Centre)	1967 - 1976	857



The below screen shot shows the set-up and results from the MUSIC for the rainwater sizing.





Figure 2

FLOODING

An investigation of Blacktown Council's online flooding maps system showed that the site is not within a high, medium or low risk flood area. The proposed floor level of the site is RL44.30 which is over 3m higher than the lowest site access point to the proposed access road. Figure 3 shows the flooding zone extents in relation to the site. The maximum level that the furthest flood zone extends to is below RL39.25. Therefore there is in excess of 1000mm freeboard to even the lowest access point of the site. This point is at the northern driveway crossover point which is at approximately RL40.50.

In accordance with the NSW Floodplain Development Manual (2005), the floor level of the development has been set so that it is not impacted by surrounding flood levels. Furthermore, the site grading and levels have been designed so that there is a safe path of egress from the site to Rooty Hill Road South that is more than 1000mm above even the highest possible flood extents.





EROSION AND SEDIMENT CONTROL

During construction, appropriate sediment and erosion control measures need to be implemented to ensure that downstream receiving water are not adversely impacted. Our drawings 17570_DA_SE01 – SE02 have detailed the required measures. These have been designed in accordance with the requirements of the Landcom – Managing Urban Stormwater - Soils and Construction, Volume 1, 4th Edition March 2004.

DRAWING LIST

The Civil DA drawings provided for submission and to be read in conjunction with this report are;

THE CIVIL DA GIAWIN	is provided for submission and to be read in conjunction with this report are;			
Drawing No.	Drawing Name			
17570_DA_C000	COVER SHEET, DRAWING SCHEDULE, NOTES & LOCALITY			
17570_DA_C100	ROAD WORKS OVERALL SITE PLAN			
17570_DA_C101	DETAIL PLANS SHEET 1 OF 4			
17570_DA_C102	DETAIL PLANS SHEET 2 OF 4			
17570_DA_C103	DETAIL PLANS SHEET 3 OF 4			
17570_DA_C104	DETAIL PLANS SHEET 4 OF 4			
17570_DA_C110	TYPICAL SECTIONS			
17570_DA_C200	STORMWATER MISCELLANEOUS DETAILS & PIT LID SCHEDULE			
17570_DA_C210	STORMWATER LONGSECTIONS SHEET 1 OF 4			
17570_DA_C211	STORMWATER LONGSECTIONS SHEET 2 OF 4			
17570_DA_C212	STORMWATER LONGSECTIONS SHEET 3 OF 4			
17570_DA_C213	STORMWATER LONGSECTIONS SHEET 4 OF 4			
17570_DA_C250	STORMWATER CATCHMENT PLAN			
17570_DA_C251	RAINWATER TANK CATCHMENT PLAN			
17570_DA_SE01	SEDIMENT AND EROSION CONTROL PLAN			
17570_DA_SE02	SEDIMENT AND EROSION CONTROL DETAILS			



We trust this serves as an adequate summary and explanation for the complex nature of the storm water and grading issues related to this site.

Yours faithfully,

TOM DEMPSEY (Senior Civil Engineer) For, and on behalf of,

H & H Consulting Engineers Pty Ltd



APPENDIX A: CIVIL DEVELOPMENT APPLICATION PLANS


ROOTY SED EZGZE NEW SH NG WORKS **IASTERN** PPING CENTRE X NSW


GENERAL NOTES:

- ALL WORK TO BE CARRIED OUT IN ACCORDANCE WITH BLACKTOWN CITY COUNCIL'S SPECIFICATION. CONTRACTOR TO OBTAIN AND RETAIN A COPY ON SITE DURING THE COURSE OF THE WORKS.
- ALL NEW WORKS ARE TO MAKE A SMOOTH JUNCTION WITH EXISTING CONDITIONS AND MARRY IN A 'WORKMANLIKE' MANNER.
- THE CONTRACTOR IS TO VERIFY THE LOCATION OF ALL SERVICES WITH EACH RELEVANT AUTHORITY. ANY DAMAGE TO SERVICES SHALL BE RECTIFIED BY THE CONTRACTOR OR THE RELEVANT AUTHORITY AT THE CONTRACTOR'S EXPENSE. SERVICES SHOWN ON THESE PLANS ARE ONLY THOSE EVIDENT AT THE TIME OF SURVEY OR AS DETERMINED FROM SERVICE DIAGRAMS. HENRY AND HYMAS CONSULTING PTY. LTD. CANNOT GUARANTEE THE INFORMATION SHOWN NOR ACCEPT ANY RESPONSIBILITY FOR INACCURACIES OR INCOMPLETE DATA.
- SERVICES & ACCESSES TO THE EXISTING PROPERTIES ARE TO BE MAINTAINED IN WORKING ORDER AT ALL TIMES DURING CONSTRUCTION.
- ADJUST EXISTING SERVICE COVERS TO SUIT NEW FINISHED LEVELS TO RELEVANT AUTHORITY REQUIREMENTS WHERE NECESSARY.
- REINSTATE AND STABILISE ALL DISTURBED LANDSCAPED AREAS.
- MINIMUM GRADE OF SUBSOIL SHALL BE 0.5% (1:200) FALL TO OUTLETS.
- ALL TEMPORARY SEDIMENT AND EROSION CONTROL DEVICES ARE TO BE CONSTRUCTED, PLACED AND MAINTAINED IN ACCORDANCE WITH THE TECHNICAL SPECIFICATIONS, EROSION AND SEDIMENTATION CONTROL PLAN AND BLACKTOWN CITY COUNCIL'S REQUIREMENTS WHERE APPLICABLE.
- CONTRACTOR TO CHECK AND CONFIRM SITE DRAINAGE CONNECTIONS ACROSS THE VERGE PRIOR TO COMMENCEMENT OF SITE DRAINAGE WORKS.
- PROPERTIES AFFECTED BY THE WORKS ARE TO BE NOTIFIED IN ADVANCE WHERE DISRUPTION TO EXISTING ACCESS IS LIKELY.

EXISTING SERVICES & FEATURES

- THE CONTRACTOR SHALL ALLOW FOR THE CAPPING OFF, EXCAVATION AND REMOVAL (IF REQUIRED) OF ALL EXISTING SERVICES IN AREAS AFFECTED BY WORKS WITHIN THE CONTRACT AREA OR AS SHOWN ON THE DRAWINGS UNLESS DIRECTED OTHERWISE BY THE SUPERINTENDENT.
- THE CONTRACTOR SHALL ENSURE THAT AT ALL TIMES SERVICES TO ALL BUILDINGS NOT AFFECTED BY THE WORKS ARE NOT DISRUPTED.
- PRIOR TO COMMENCEMENT OF ANY WORKS THE CONTRACTOR SHALL GAIN APPROVAL OF HIS PROGRAM FOR THE RELOCATION/ CONSTRUCTION OF TEMPORARY SERVICES.
- CONTRACTOR SHALL CONSTRUCT TEMPORARY SERVICES TO MAINTAIN SUPPLY TO EXISTING BUILDING REMAINING IN OPERATION DURING WORKS TO THE SATISFACTION AND APPROVAL OF THE SUPERINTENDENT. ONCE DIVERSION IS COMPLETE AND COMMISSIONED, THE CONTRACTOR SHALL REMOVE ALL SUCH TEMPORARY SERVICES AND MAKE GOOD TO THE SATISFACTION OF THE SUPERINTENDENT.
- INTERRUPTION TO SUPPLY OF EXISTING SERVICES SHALL BE DONE SO AS NOT TO CAUSE ANY INCONVENIENCE TO THE PRINCIPAL. CONTRACTOR TO GAIN APPROVAL FROM THE SUPERINTENDENT FOR TIME OF INTERRUPTION.
- EXISTING SERVICES, BUILDINGS, EXTERNAL STRUCTURES AND TREES SHOWN ON THESE DRAWINGS ARE EXISTING FEATURES PRIOR TO ANY DEMOLITION WORKS.
- EXISTING SERVICES UNLESS SHOWN ON SURVEY PLAN HAVE BEEN PLOTTED FROM SERVICES SEARCH PLANS AND AS SUCH THEIR ACCURACY CANNOT BE GUARANTEED. IT IS THE RESPONSIBILITY OF THE CONTRACTOR TO COMPLETE A 'DIAL BEFORE YOU DIG' SEARCH AND TO ESTABLISH THE LOCATION AND LEVEL OF ALL EXISTING SERVICES PRIOR TO THE COMMENCEMENT OF ANY WORK. ANY DISCREPANCIES SHALL BE REPORTED TO THE SUPERINTENDENT. CLEARANCES SHALL BE OBTAINED FROM THE RELEVANT SERVICE
- ALL BRANCH GAS AND WATER SERVICES UNDER DRIVEWAYS AND BRICK PAVING SHALL BE LOCATED IN Ø80 uPVC SEWER GRADE CONDUITS EXTENDING A MINIMUM OF 500mm BEYOND EDGE OF PAVING.





LOCALITY PLAN

SCALE: NTS

	DRAWING SCHEDULE
17570_DA_C000	COVER SHEET, DRAWING SCHEDULE, NOTES AND LOCALITY SKETCH
17570_DA_C100	GENERAL ARRANGEMENT PLAN
17570_DA_C101	DETAIL PLANS, SHEET 1 OF 4
17570_DA_C102	DETAIL PLANS, SHEET 2 OF 4
17570_DA_C103	DETAIL PLANS, SHEET 3 OF 4
17570_DA_C104	DETAIL PLANS, SHEET 4 OF 4
17570_DA_C110	TYPICAL SECTIONS
17570_DA_C200	STORMWATER MISCELLANEOUS DETAILS AND PIT LID SCHEDULE
17570_DA_C210	STORMWATER LONGITUDINAL SECTIONS SHEET 1 OF 4
17570_DA_C211	STORMWATER LONGITUDINAL SECTIONS SHEET 2 OF 4
17570_DA_C212	STORMWATER LONGITUDINAL SECTIONS SHEET 3 OF 4
17570_DA_C213	STORMWATER LONGITUDINAL SECTIONS SHEET 4 OF 4
17570_DA_C250	STORMWATER CATCHMENT PLAN
17570_DA_C251	RAINWATER TANK CATCHMENT PLAN
17570_DA_SE01	SEDIMENT AND EROSION CONTROL PLAN
17570_DA_SE02	SEDIMENT AND EROSION CONTROL DETAILS

SITEWORKS NOTES

- ORIGIN OF LEVELS : REFER TO BENCH OR STATE SURVEY MARKS WHERE SHOWN ON PLAN. DATUM : A.H.D.
- CONTRACTOR MUST VERIFY ALL DIMENSIONS AND EXISTING LEVELS ON SITE PRIOR TO THE COMMENCEMENT OF WORK.
- ALL WORKS TO BE UNDERTAKEN IN ACCORDANCE WITH THE DETAILS SHOWN ON THE DRAWINGS & THE DIRECTIONS OF THE SUPERINTENDENT.
- EXISTING SERVICES UNLESS SHOWN ON THE SURVEY PLAN HAVE BEEN PLOTTED FROM SERVICES SEARCH PLANS AND AS SUCH THEIR ACCURACY CANNOT BE GUARANTEED. IT IS THE RESPONSIBILITY OF THE CONTRACTOR TO ESTABLISH THE LOCATION AND LEVEL OF ALL EXISTING SERVICES PRIOR TO THE COMMENCEMENT OF ANY WORK. ANY DISCREPANCIES SHALL BE REPORTED TO THE SUPERINTENDENT. CLEARANCES SHALL BE OBTAINED FROM THE RELEVANT SERVICE AUTHORITY.
- WHERE NEW WORKS ABUT EXISTING THE CONTRACTOR SHALL ENSURE THAT A SMOOTH EVEN PROFILE, FREE FROM ABRUPT CHANGES IS ACHIEVED.
- THE CONTRACTOR SHALL ARRANGE ALL SURVEY SETOUT TO BE CARRIED OUT BY A REGISTERED SURVEYOR.
- CONTRACTOR TO OBTAIN AUTHORITY APPROVALS WHERE APPLICABLE CARE IS TO BE TAKEN WHEN EXCAVATING NEAR EXISTING SERVICES. NO MECHANICAL EXCAVATION IS TO BE UNDERTAKEN OVER TELSTRA OR ELECTRICAL SERVICES. HAND EXCAVATE IN THESE AREAS.

MAKE SMOOTH TRANSITION TO EXISTING SURFACES AND MAKE GOOD.

- THESE PLANS SHALL BE READ IN CONJUNCTION WITH APPROVED LANDSCAPE, ARCHITECTURAL, STRUCTURAL, HYDRAULIC AND MECHANICAL DRAWINGS AND SPECIFICATIONS OR WRITTEN INSTRUCTIONS THAT MAY BE ISSUED RELATING TO DEVELOPMENT AT THE SITE.
- TRENCHES THROUGH EXISTING ROAD AND CONCRETE PAVEMENTS SHALL BE SAWCUT TO FULL DEPTH OF CONCRETE AND A MINIMUM OF 50mm IN BITUMINOUS PAVING.
- ALL BRANCH GAS AND WATER SERVICES UNDER DRIVEWAYS AND BRICK PAVING SHALL BE LOCATED IN Ø80 uPVC SEWER GRADE CONDUITS EXTENDING A MINIMUM OF 500mm BEYOND EDGE OF PAVING.
- GRADES TO PAVEMENTS TO BE AS IMPLIED BY RL'S ON PLAN . GRADE EVENLY BETWEEN NOMINATED RL'S. AREAS EXHIBITING PONDING GREATER THAN 5mm DEPTH WILL NOT BE ACCEPTED UNLESS IN A DESIGNATED SAG POINT.
- ALL COVERS AND GRATES ETC TO EXISTING SERVICE UTILITIES ARE TO BE ADJUSTED TO SUIT NEW FINISHED SURFACE LEVELS WHERE APPLICABLE.

SURVEY NOTES

THE EXISTING SITE CONDITIONS SHOWN ON THE FOLLOWING DRAWINGS HAVE BEEN INVESTIGATED BY THE SURVEYOR SPECIFIED IN THE TITLE BLOCK.

THE INFORMATION IS SHOWN TO PROVIDE A BASIS FOR DESIGN. HENRY AND HYMAS PTY. LTD. DOES NOT GUARANTEE THE ACCURACY OR COMPLETENESS OF THE SURVEY BASE OR ITS SUITABILITY AS A BASIS FOR CONSTRUCTION DRAWINGS.

SHOULD DISCREPANCIES BE ENCOUNTERED DURING CONSTRUCTION BETWEEN THE SURVEY DATA AND ACTUAL FIELD DATA, CONTACT HENRY AND HYMAS PTY. LTD. THE FOLLOWING NOTES HAVE BEEN TAKEN DIRECTLY FROM ORIGINAL SURVEY DOCUMENTS.

ORIGIN OF LEVELS

PM 30122 - RL 43.58

DATUM


A.H.D


ONLY

copied in whole or in part without the prior written app	DATE	DRAWN DESIGNED	DRAWN	AMENDMENT	REVISION	DATE	DESIGNED	DRAWN	MENDMENT
This drawing and design remains the property of Henry						30.08.2017	TC	₹	
12C ARCHITECTS									
Architect									
FRASER PROPERTY ALISTRA									

INFORMATION
SURVEYED BY LANDPARTNERS
DATUM: AHD
ORIGIN OF LEVELS: PM 30122 - RL 43.58

SURVEY











PROPOSED NEW SHOPPING CENTRE ROOTY HILL ROAD SOUTH, EASTERN CREEK NSW ET, DRAWING SCHEDULE LOCALITY SKETCH


7570 T.Chan DA C000 NTS @ A1 JULY 2017 01




















ONLY


AS NOTED @ A1


02




















THE SEDIMENT BASIN SHALL BE CONSTRUCTED ON A RATE PER HECTARE BASIS AND HAS BEEN IN ACCORDANCE WITH THE REQUIREMENTS OF THE LANDCOM MANUAL "MANAGING URBAN STORMWATER - SOILS AND CONSTRUCTION", FOR SEDIMENTATION TYPE D SOILS. THE DISTURBED AREA WITHIN THIS CATCHMENT AT ANY ONE TIME SHOULD BE LIMITED TO AN AREA FOR WHICH EACH SEDIMENT BASIN CAN HANDLE. EACH BASIN SHALL BE SIZED IN ACCORDANCE WITH THE TABLE BELOW.

71.25 m³/Ha	TOTAL SEDIMENT BASIN VOLUME REQUIRED :
14.5m³ < 50% SETTLING VOL	SEDIMENT ZONE VOLUME (0.17 A (R K LS P C)/1.3
110.87m³	RKLSPC
1 Ha (UNIT AREA)	DISTURBED CATCHMENT AREA
47.5 m³	SETTLING ZONE VOLUME (PER HECTARE) 10 CV A R
1 Ha (UNIT AREA)	CATCHMENT AREA, A
19.0 mm	75TH PERCENTILE 5 DAY TOTAL RAINFALL DEPTH, R
0.25 (APPENDIX F - TABLE F2)	VOLUMETRIC RUNOFF COEFFICIENT, CV
SEDIMENT BASIN SIZING TYPE D SOILS	SEDIMENT BASIN S

* (LANDCOM MANAGING URBAN STORMWATER MANUAL REFERENCE)
2. THE FOLLOWING DESIGN PARAMETERS HAVE BEEN ASSESSED FOR THE SITE:

		SC	CALCI	CO	EROSIO	N SOI	LENGTH	RAINI	
75TH PERCENTILE 5-DAY RAINFALL EVENT	SEDIMENT TYPE	SOIL HYDROLOGIC GROUP	CALCULATED SOIL LOSS, A (RUSLE EQUATION)	COVER FACTOR (C-FACTOR)	EROSION CONTROL PRACTICE FACTOR (P-FACTOR)	SOIL ERODIBILITY (K-FACTOR)	LENGTH/SLOPE GRADIENT FACTOR, LS	RAINFALL EROSIVITY (R-FACTOR)	CONSTRAINT
19.0mm (BLACKTOWN)	TYPE D	GROUP C	110.87t/Ha/YR	1.0 (DURING EARTHWORKS)	1.3 (COMPACTED)	0.038	0.955	2350	VALUE
TABLE 6.3A	APPENDIX C TABLE 4	APPENDIX C TABLE 20	A=RKLSPC	APPENDIX A - FIGURE A5	APPENDIX A - TABLE A2	(TABLE C20 - BLACKTOWN)	APPENDIX A - TABLE A1	APPENDIX B	(SOURCE)*

MANAGING URBAN STORMWATER MANUAL REFERENCE)

BASIN MANAGEMENT

- THE CAPTURED STORMWATER IN THE SETTLING ZONE SHOULD BE DRAINED TO MEET THE MINIMUM STORAGE CAPACITY REQUIRED WITHIN A FIVE (5) DAY PERIOD FOLLOWING RAINFALL, PROVIDED THE ACCEPTABLE WATER QUALITY (NFR) AND TURBIDITY HAVE BEEN ACHIEVED.
- CHEMICAL FLOCCULENT SUCH AS GYPSUM MAY BE DOSED TO AID SETTLING WITHIN 24 HOURS OF CONCLUSION OF EACH STORM. THE APPLIED DOSING RATES SHOULD ACHIEVE THE TARGET QUALITY WITHIN 36 TO 72 HOURS OF THE STORM EVENT.
- INSPECT THE SEDIMENT BASINS AFTER EACH RAINFALL EVENT AND/OR WEEKLY. ENSURE THAT ALL SEDIMENT IS REMOVED ONCE THE SEDIMENT STORAGE ZONE IS FULL (REFER TO PEGS INSTALLED IN BASINS IN ACCORDANCE WITH THE SWMP). ENSURE THAT OUTLET AND EMERGENCY SPILLWAY WORKS ARE MAINTAINED IN A FULLY OPERATIONAL CONDITION AT ALL TIMES.

OATS@20kg/Ha+ JAPANESE MILLET@20kg/Ha	SPRING/SUMMER
OATS@40KG/Ha+ JAPANESE MILLET@10kg/Ha	AUTUMN/WINTER
SEED MIX	SOWING SEASON

NOTE : THESE PLANT SPECIES ARE FOR TEMPORARY REVEGETATION ONLY. THEY WILL ONLY PROVIDE PROTECTION FROM EROSION FOR SIX MONTHS. WHERE THE LOTS ARE TO BE LEFT UNDEVELOPED FOR A LONGER PERIOD, THE CONTRACTOR SHALL SEEK ADVICE FROM THE SITE SUPERINTENDENT AS TO MORE APPROPRIATE REVEGETATION METHODS.

REVEGETATION IN ACCORDANCE WITH THE ABOVE TABLE WILL BE ENHANCED BY ADDING LIME AT A RATE OF 4kg/TONNE OF TOPSOIL AND 7.5kg/TONNE OF SUBSOIL.

THE LONG TERM GROUND COVER FACTORS FOR THE CONSTRUCTION WORKS IS NOT TO EXCEED THE FOLLOWING LIMITS:

ALL LANDS, INCLUDING WATERWAYS AND STOCKPILES, DURING CONSTRUCTION.	STOCKPILES, POST CONSTRUCTION	WATERWAYS AND OTHER AREAS OF CONCENTRATED FLOWS, POST CONSTRUCTION	LAND
0.15	0.10	0.05	MAXIMUM C-FACTOR
APPLIES AFTER 20 DAYS OF INACTIVITY, EVEN THOUGH WORKS MAY BE INCOMPLETE. 50% GROUND COVER IS REQUIRED.	APPLIES AFTER TEN WORKING DAYS FROM COMPLETION OF FORMATION. 60% GROUND COVER IS REQUIRED.	APPLIES AFTER TEN WORKING DAYS OF COMPLETION OF FORMATION AND BEFORE CONCENTRATED FLOWS ARE APPLIED. FOOT AND VEHICULAR TRAFFIC IS PROHIBITED IN THIS AREA AND 70% GROUND COVER IS REQUIRED.	REMARKS

<u>.</u>≪

T.Chan NTS @ A1 JULY 2017

7570 DA S E02

SEDIMENT AND EROSION CONTROL TYPICAL SECTIONS AND DETAILS

This drawing and design remains the property of Henry & Hymas and may not be copied in whole or in part without the prior written approval of Henry & Hymas.

henrykhymas

9



APPENDIX B: STORMWATER MAINTENANCE MANUALS



Level 5, 79 Victoria Avenue CHATSWOOD NSW 2067

Ph: +61 2 9417 8400 Fx: +61 2 9417 8337 E-mail: email@hhconsult.com.au Web: www.herryandhymas.com.au

MAINTENANCE SCHEDULE

MAINTENANCE ACTION	FREQUENCY	RESPONSIBILITY	PROCEDURE
Enviropod Pit Baskets			
-	(Refer to SW360 maintenance schedule/handbook)	Owner/Maintenance Contractor	(Refer to SW360 maintenance schedule/handbook)
Grass Lined Swale(s)			
Sediment deposition	Three monthly or after heavy rain	Maintenance Contractor	Remove sediment build up from swale and in and around trees
Holes or Scour	Three monthly or after heavy rain	Maintenance Contractor	Infill any holes in the turf/grass area. Check for erosion or scour repair. Provide energy dissipation (eg. Rocks and pebbles at inlet) if necessary.
Litter Control	Three monthly or as desired for aesthetics	Maintenance Contractor	Check for litter (including organic litter) in and around the swale area. Remove both organic and anthropogenic litter to ensure flow paths is maintained.
Pests and diseases	Three monthly or as desired for aesthetics	Maintenance Contractor	Assess plants for disease, pest infection, stunted growth or senescent plants. Treat or replace as necessary. Reduced plant density reduces pollutant removal and performance
Maintain original plant densities	Three monthly or as desired for aesthetics	Maintenance Contractor	Infill planting – between 6 and 10 plants per square metre should be adequate (depending on species) to maintain a density where the plants' roots touch each other. Planting should be evenly spaced to help prevent scouring due to a concentration of flow.
Weeds	Three monthly or as desired for aesthetics	Maintenance Contractor	Inspect for and manually remove weed species. Application of herbicide should be limited to a wand or restrictive spot spraying due to the fact that the swale is directly connected to the waterways.
Inspection after rainfall	Twice a year after rain	Maintenance Contractor	Occasionally observe the swale system after a rainfall event to check infiltration. Identify signs of poor drainage (extended ponding). If poor drainage is identified, check land use and assess whether it has altered from design capacity (eg. Unusually high sediment loads may require installation of a sediment forebay).

MAINTENANCE ACTION	FREQUENCY	RESPONSIBILITY	PROCEDURE
Stormwater Pits, Grated			
Drains and Pipes			
Pits, grated drains and pipes around the site	Annually	Maintenance Contractor	Check pits, grated drains and pipes for blockages. Remove debris and flush pipes if required.
Check step irons for corrosion	Annually	Maintenance Contractor	Remove grate. Examine step irons and repair any corrosion or damage.
Check fixing of step irons is secure	Six monthly	Maintenance Contractor	Remove grate and ensure fixings secure prior to placing weight on step iron.
Rainwater Sprinkler Tank			
Refer to manufacturer or tank suppliers recommendations	As per suppliers recommendations	Maintenance Contractor	As per suppliers recommendations

Yours sincerely,


Tom Dempsey
For, and on behalf of,

H & H Consulting Engineers Pty Ltd

Our Ref: 17570/td Date: 31/08/17

Operations and maintenance

StormFilter® EnviroPod Treatment Train





Device details			
Location of Device	се		
GPS Coord	N:	E:	D P Number:
Relevant Council			
Company			
Contact		Email	Ph
Engineer			
Contact		Email	Ph
2			
	pection/Mainter	nance	Maintenance Estimated Annual Cost
2 Frequency of Ins	ections	Major	Maintenance Estimated Annual Cost StormFilter
2 Frequency of Ins Inspe			
2 Frequency of Ins	ections	Major	StormFilter
2 Frequency of Ins Inspe	ections	Major	StormFilter EnviroPod
2 Frequency of Ins Inspe	ections	Major	StormFilter EnviroPod

Contents			The Stormwater Management StormFilter		
001110			1.1	Description	18
Treatment Train Specifications			1.2	Operation	18
Introduction Why cleaning and maintenance are so vitally important			1.2.1	Purpose	18
			1.2.2	Sizing	18
			StormFilter overview		18
Health and safety		5	1.2.3	Basic function	19
2.1	Personnel health and safety	6 7	1.2.4	Priming system function	19
2.2			1.2.5	Maintenance overview	19
2.3	Confined spaces	7	StormFi	Iter maintenance and	
3.1	Maintenance and monitoring of EnviroPod filters	8	performance expectations		
Operations		8	2.1	Types of maintenance	21
3.2	Stormwater pit cover removal	9	2.2	Maintenance activities	22
3.2.1	3.2.1 Hinged pit grates3.2.2 Non-hinged pit grates3.3 Cleaning methods		2.2.1 2.2.2 2.3	Maintenance activity timing	22
3.2.2				Maintenance activity frequency	22
3.3				Maintenance crew requirements	22
3.3.1	Cleaning using an inductor truck	11	2.4	Maintenance methods	23
3.3.2 Hand	Hand maintenance	11 14	2.4.1	Minor maintenance/inspection (twice a year)	23
3.4	Unit inspection		2.4.2		24
3.5	Filter bag inspection and rejuvenation	14	2.4.3		
3.5.1	Clogged filters	14	20	cartridge replacement (and emergency)	24
3.5.2	Damaged filters	15	2.4.4		
3.6	Disposal of material	15		(performed on an as-needed basis)	26
4.1	Spill procedures	16	2.5	Typical equipment required for	
4.2	Blockages	16		maintenance activities	26
Emergency procedures		16	2.6	Material Disposal	27
			Next ste	ps	30

Maintaining the EnviroPod® Stormwater Gully Pit Insert

Maintenance is as integral to every stormwater management system as it is to any other item of machinery or equipment.

The primary purpose of the EnviroPod® Stormwater Gully Pit insert is to filter out and remove pollutants from entering our waterways. To ensure that the EnviroPod® continues to function effectively, it is important that the pollutants it captures are periodically removed, and the filtration components properly cleaned.

Maintenance requirements and frequency are dependent on the pollutant load characteristics of each site, as well as the occurrence of events such as chemical spills or excessive sediment loading due to site erosion or extreme storms. Similarly, the system should be inspected after all major storm events.

Treatment Train Specifications



Performance Specification

The stormwater filtration treatment train shall consist x 200 micron gully pit basket/s and 460/690mm passive, siphon-actuated, radial flow, self cleaning media filtration cartridge system/s operating at a specific flow rate of not more than 1.5L/s/m².

The gully pit basket system shall consist of the following components;

- Removable 200 micron Nylon monofilament Precision woven Filtration Bag
- Fixed Galvanised Mesh Cage (no greater than 80mm x 80mm) around the Filtration Bag
- Recycled modified ABS plastic to seal the unit into the pit
- By-pass mechanism above the Filter with no moving parts
- System rigidly fixed to the walls of the pit.

The media filtration system shall be located within the following structure.

- Manhole
- DownPipe
- Linear
- Vault
- Large Box
- Detention.

Regardless of the system type, the media filtration system shall consist of the following components;

- Inlet energy dissipation
- Cartridge section
- Outlet section to bypass storm flows and convey treated stormwater
- Access Lids in roof slab for access to Cartridges
- Siphon actuated cartridges filled with proprietary ZPG™ filter media
- Specific flow rate of each individual cartridge limited not to exceed 1.5L/s/m²
- Air Lock Cap complete with one way Air Valve Flap
- Outer Hood complete with Scrubbing Regulators
- Automated high-energy turbulence on the screen face (only) at the end of storm flows to flush pollutants from the cartridge
- Centre Drainage Tube complete with Buoyancy Float
- Individual Cartridge Flow Restrictor Disc
- 1/4 Turn Bayonet Fittings
- Under drain manifold to convey treated stormwater to the receiving environment.

Components of any proposes treatment train or technology



The components of any proposed the treatment train or technology, including a gully pit basket upstream of a radial flow cartridge filtration system, must be evaluated for a range of pollutants and these performance expectations must comply with current best practice guidelines, i.e. Water by Design "MUSIC Modeling Guidelines version 1.0 2010" for South East Queensland.

In short, the performance evaluation of any system must show:

- Any reduction efficiencies are justified by rigorous scientific testing as determined by an independent peer reviewer and the results further peer reviewed and published in a credible scientific journal. Any potential or perceived conflicts of interest should be disclosed within the published article.
- Published article providing insight into the pollutant composition (e.g. soluble vs particulate for nitrogen) and the mean concentration of inflow and outflow to compare to local and or regional conditions.
- Performance evaluation undertaken in dry weather conditions or a method to take into account any potential leaching of nutrients that may occur in the system(s).
- Evaluation is conducted using full-scale systems with details of treatable flow rates sampled and how they correlate to discrete removal efficiencies and comparisons to the designed treatable flow rates of the device. A comparison should also be made to the climatic conditions especially where un-restricted filters are used.

Maintenance Overview

The primary purpose of the Stormwater Treatment Train is to filter out and prevent pollutants from entering our waterways. Like any effective filtration system, periodically these pollutants must be removed to restore the system to its full efficiency and effectiveness.

Maintenance requirements and frequency are dependent on the pollutant load characteristics of each site. Maintenance must be performed in accordance with the Treatment Trains Operation and Maintenance Guidelines.





This manual has been designed to assist you with cleaning and maintaining the EnviroPod Stormwater Gully Pit Insert, using the methods recommended by the manufacturer.

The cleaning process and methods described cover all aspects of the system, including:

- · Removing the grate
- Cleaning the filter bag
- Inspecting the unit
- Rejuvenating the filter bag
- Re-installing the filter bags.

The manual should be used in conjunction with your site's traffic management and safety plans, as well as other appropriate Stormwater360 (IES) documents such as the IES Employee Health and Safety Manual. We also recommend that maintenance and cleaning contractors, or device owners, develop their own site-specific health and safety activity plans to ensure a safe work environment.



Please note: This manual consists primarily of the processes and tasks associated with the hand maintenance and inductor maintenance procedures. It does not include details of the and safety requirements. Contractors or IES and Safety Manual, which details the policies and procedures for safe work.

Why cleaning and maintenance are so vitally important

Adhering to the inspection and maintenance schedule of each stormwater treatment device is essential to ensuring that it works properly throughout its estimated design life.

During each inspection and clean, details of the mass, volume and type of material that has been collected by the device should be recorded. This data will assist with the revision of future management plans and help determine maintenance interval frequency. It's also essential that qualified and experienced personnel carry out all maintenance (including inspections, recording and reporting) in a systematic manner. To ensure consistency, we recommend that one person be responsible for overseeing the management of the maintenance and cleaning process.

Maintenance of your stormwater management system is essential to ensuring ongoing at-source control of stormwater pollution. Maintenance also helps prevent structural failures (e.g. prevents blocked outlets) and aesthetic failures (e.g. debris build up).

Health and safety



The EnviroPod has been designed to trap and retain pollutants in stormwater runoff, helping to maintain the quality of water entering our aquatic ecosystems. Depending on the nature of your site, pollutants can range from organic material such as leaves and sticks through to debris such as broken glass, syringes or other potentially harmful materials.

Access to gully pits containing EnviroPods may require removing heavy protective grates, while cleaning such pits may entail working in confined spaces. For these reasons, all aspects of maintaining and cleaning your EnviroPod require careful adherence to Occupational Health and Safety (OH&S) guidelines. Doing so will ensure that all maintenance personnel are adequately protected and have been properly trained before taking part in any specialist activities. The same level of care needs to be taken to protect non-work personnel in and around the site, while appropriate traffic control measures must be put in place where collection pits are situated in, or adjacent to, roadways or car parks.

The procedures indicated in the Operations section of this manual are recommended as the safest and most efficient manner of conducting the maintenance of EnviroPod units (Section 2), however contractors and cleaning staff may vary the procedure in response to the site conditions; varying work practices; or general preferences in the cleaning techniques. Please note that procedures outlined in this manual are not exhaustive, and that any changes made should always comply with general safe

Cleaning of EnviroPod filters and StormFilters is a specialist activity. The material collected by the devices can be harmful, and needs to be handled correctly. For example, sediments may contain heavy metals and carcinogenic substances as well as harmful objects such as broken glass and syringes. It is essential that Occupational Safety and Health guidelines are followed at all times, and that the following steps are carried out to ensure safe and successful maintenance operations.

In addition to the dangers associated with the cleaning and handling of material in the filter bags, precaution needs to be taken with activities such as removing the grate as well as with managing the traffic, pedestrians and other nonworker personnel at the site. The general workplace hazards associated with working outdoors also need to be taken into account.

2.1 Personnel health and safety

All contractors and staff must comply with all current workplace health and safety legislation and take all practicable

- Comply with all applicable laws, regulations and standards
- Ensure that all employees, contractors and visitors are informed of and understand their obligations in respect of current workplace health and safety legislation
- Ensure that employees understand and accept their responsibility to practice and promote a safe and healthy work environment.

Take proper care. Pollutants can range from organic materials such as leaves and sticks through to debris such as broken glass, syringes or other potentially harmful materials. While cleaning and maintaining filters, all relevant precautions must be taken to prevent contact with sediment and litter. This includes wearing the following personal protective and safety equipment:

- Puncture resistant gloves
- Steel capped safety boots
- Fluorescent safety vest
- Overalls or similar skin protection
- Safety apron (if necessary)*
- Eye protection (if necessary)*.
- * Higher personal safety conditions may be required when maintaining units that may contain more hazardous material, for example pits where syringes have been observed or pits located in areas associated with such activities.



2.2 Traffic control

Stormwater collection pits are typically situated either in or on roads and car parks, or adjacent to roads in a footpath or swale. Traffic control requirements across all such locations differ with most of the state and local road authorities requiring the same controls to be implemented whether the work is to be conducted on the road or on the road reserve.

As traffic requirements differ depending on road usage and the specific road configuration, separate traffic control plans should be prepared for each site. Given that maintenance is typically a quick process, the contractor should liaise with the relevant road authority to determine the specific road safety requirements for each location to ensure that on site workers can conduct the cleaning operations safely and efficiently, while complying with all laws and regulations.

State government publications such as the NSW RMS Traffic Control at Work Sites safety manual outline the signage requirements, placement of barricades or witches hats and the positioning of traffic control personnel that's required when working on public roads. For increased safety, IES recommends that the maintenance vehicle be used to shield the work area from oncoming traffic.

Photo 1 shows the maintenance vehicle with cones placed around and positioned to shield the work area. Photo 2 shows the head-on view, note the vehicle is positioned to allow access to the drive, whilst still blocking the pit from on-coming traffic. The vehicle has a flashing light on the roof and the hazard lights switched on.

Photo 1 Vehicle positioned near pit, preventing traffic from passing close to the pit.

2.3 Confined spaces

Confined space entry procedures are not included as part of this manual. For IES employees these procedures are included as part of the IES Safety Manual. It is recommended that all contractors evaluate their own needs for confined space entry and compliance with Occupational Health and Safety regulations.

When repairs or maintenance activities cannot be conducted from the surface, and there is a need to enter and work in a confined space, only staff with current confined space training are permitted to operate in a confined space. Appropriate measures and controls must be put in place to meet confined space entry requirements. At all times the necessary safety equipment must be worn, and where gas or oxygen hazards occur, only staff trained in its use will use breathing apparatus gear. Non-trained staff must not go into confined spaces.

Confined spaces pose a serious safety hazard for all personnel; however during the normal maintenance procedures there should be no reason to enter a confined space and all maintenance procedures are able to be conducted from the surface.



Photo 2 Head-on view, indicating the placement of the vehicle near the pit.

Operations



EnviroPod units need to be regularly inspected to determine whether they require maintenance or cleaning. This process involves several steps, and may require two or more maintenance personnel working together, as well the use of specialised equipment such as a hydraulic lifting arm or an inductor truck with a vacuum hose.

As gully pit grates are usually quite heavy, it is important that correct lifting procedures are adopted, and that the area surrounding the opened pit is shielded from access to non-work personnel.

If inspection reveals that the filter bag needs to be emptied and rejuvenated, the entire unit should also be examined to ensure that all connections and joints are sound. Any material that has accumulated in the overflow diversion channels or outlet pipes also needs to be removed, with those areas then being flushed. Where required, filter bags may need to be cleaned or repaired, and all waste material must be disposed of according to local guidelines at either an approved disposal site or transfer station.

This section outlines the procedures for cleaning the EnviroPod units. It has been written so that someone who has never previously encountered a stormwater pit or an EnviroPod unit can carry out such maintenance by simply following the outlined steps.

3.1 Maintenance and monitoring of EnviroPod filters

To ensure that each EnviroPod unit achieves optimal performance, the material collected by the filter bag should be emptied when the level of material is no more than approximately half to two thirds of the total bag depth or when there is evidence of material overflow. While the bag has a greater storage capacity, it is recommended that it is not left to fill completely prior to emptying, for the following reasons:

- the bags are capable of retaining a heavy mass of material (in excess of 50kg), which will make them more difficult to lift and empty
- material near the top of the bag can be re-suspended during high to extreme rainfall events
- blockage of the overflow sections can occur, when material is allowed to build up above the filter bag.

It is also recommended that additional monitoring is conducted following moderate to extreme rainfall events, especially when preceding months have had little or no rainfall. This increased frequency of monitoring is necessary as there is a greater accumulation of surface contamination during low rainfall periods, which will then enter the unit with the higher volumes of runoff generated during a major rainfall event. It is also important to ensure that the units have not been damaged due to high pipe velocities.

3.2 Stormwater pit cover removal

3.2.1 Hinged pit grates

These are the steps for opening a hinged pit grate:

- Insert the lifting hooks beneath the grate. (Position indicated in Photo 3)
- Check hinge point is not damaged and debris is not caught in the hinge area.
- Fully open pit grate, ensuring that the grate will stay in the open position without any external forces applied. Grates that do not remain open without being held should be removed or secured during cleaning or maintenance activities. Photo 4 indicates the grate being opened and grate resting freely in the open position, respectively.

Please note: Many cast iron hinges are not hinged securely (to enable the removal of the grate). This may result in the pit grate not being able to sit in an open position. Additionally the hinge pins may also be damaged or corroded, which may allow the grate to fall into the pit. Such pit grates can be removed using the method indicated below for non-hinged grates.



Photo 3 Lifting the grate



Photo 4 Fully open grate



Photo 5 Lowering grate

3.2.2 Non-hinged pit grates

To remove a non-hinged pit grate:

- Place lifting hooks beneath grate, where possible in the four corners of the grate (see Photo 6). Concrete lids may have Gatic lifting points, a key arrangement or holes in the lid, which may require special equipment such as Gatic lifters
- Position each person either side of the grate (see Photo 7)
- Lift the grate, ensuring that good heavy lifting posture is used at all times
- Place the grate on an angle on the gutter, to allow for the lifting hooks to be removed (see Photo 8)
- For extremely heavy one-piece grates and concrete Gatic covers, insert the lifters in place and slide the lids back. Note some lids may still require two people



Photo 6 Insert hook near edge of grate



Photo 7 Position each lifter either side of the grate



Photo 8 Lift grate and move grate to one side



Photo 9 Lift grate above the support frame



Photo 10 Reinstated non hinged grate

3.3 Cleaning methods

One of the following maintenance methods should be used for servicing EnviroPod Filters:

3.3.1 Cleaning using an inductor truck

Follow these steps to safely and efficiently clean the EnviroPod using an inductor truck:

- Open gully pit (See Section 3.2)
- Place the inductor hose over the material collected in the filter bag and switch on the inductor
- Using the inductor hose, suck out all of the sediment, organic leaf material, litter etc. collected in the filter bag
- Allow the filter bag to be sucked up into the inductor hose for a few seconds to allow for the filter mesh pores to be cleaned. Care is to be taken that there are no sharp edges on the inductor hose that can damage the filter bag
- If material has built up around the overflows, use the inductor hose to clear the accumulated material
- Remove filter bag from the pit
- 7 Sediment retained in the gully pit grate is to be removed
- Back-opening channels are to be cleared of any debris to ensure flow is not hindered. This debris can also be collected using the inductor truck
- 9 All gully pit waste is to be removed from the pit
- 10 Check the EnviroPod unit (Section 3.4)
- 11 Check filter bag (Section 3.4)
- Reinstate filter bag and gully pit lids



Photo 11 Cleaning an EnviroPod using the inductor method

3.3.2 Hand maintenance

To clean the EnviroPod manually by hand, follow these steps:

- Open gully pit (See Section 1)
- Place the lifting hooks in the lifting loops of the filter bag (See Photo 12)
- For extremely heavy and overfilled bags either use a hydraulic lifting arm to lift the bag, or remove excess material using a shovel or similar piece of equipment. IES prefers the use of a post hole shovel, due to the reduced strain on the back when digging and the ability of the shovel to grab material vertically
- Lift the bag vertically off the supporting frame, ensuring that no undue pressure is placed on the filter bag. (See Photo 13)
- Lift the bag clear of the stormwater pit (See **Photo 14**)
- Position the bag over the truck or other collection vehicle, taking hold of the loops at the base of the bag (See Photo 15 and Photo 16)
- Lift and empty the filter bag by holding the bottom lifting loops only (See **Photo 17**)
- 8 Completely empty the filter bag (See Photo 18)
- Brush the filter bag with a stiff brush to remove bound sediment from the filter pores
- 10 Check the EnviroPod unit (Section 3.4)
- 11 Check the filter bag (Section 3.5)
- Reinstate filter bag, ensuring bag is installed the correct way (See **Photo 19** and **Photo 20**)
- Reinstate gully pit lids (See Photo 21 and Photo 22)



Photo 12 Place the lifting hooks through the bag loops



Photo 13 Lift the bag from the cage and support frame



Photo 14 Lift the bag from the stormwater pit



Photo 15 Lift the bag onto the collection vehicle



Photo 16 Grab the bottom lifting loops



Photo 17 Lifting the bottom bag loops empty the filter bag



Photo 18 Completely empty the contents of the filter bag



Photo 19 Reinstall filter bag



Photo 20 Ensure that the unit is positioned correctly, with the lifting loops on the inside



Photo 21 Correctly installed filter bag



Photo 22 Installed filter bag and sealed pit

Please note: Under no circumstances are the gully pit.



Photo 23 Check seals are pushed against the pit walls



Photo 24 Check joining rivets (two piece unit shown above)

3.4 Unit inspection

After the EnviroPod filter bag has been removed, emptied and cleaned, the following should be checked to ensure that the unit has not been damaged:

- All connections and joints should be checked and broken rivets replaced (See Photo 23)
- The plastic pit seals should be inspected for unit movement or damage (See Photo 24)
- The cage should be inspected for damage or movement.

The overflow diversion channels, and the area between the EnviroPod cage and pit wall should also be inspected for any accumulated debris. Any observed debris should be removed and disposed of off-site. Accumulated material within the outlet pipe may also need to be flushed.

If spare parts are required, Stormwater 360 is able to provide these at a cost to the owner of the EnviroPod unit, although these parts may also be obtained from other suppliers.

Please note: If the units are not cleaned regularly, the mobilisation of material collected in the EnviroPod unit may occur. As such, cleaning of the units in accordance with this management plan is required. As this plan is based on observations and data collected during the monitoring period, ongoing adjustment of the cleaning frequency is generally required to improve the overall and prevent material overflow.

3.5 Filter bag inspection and rejuvenation

After the filter bags have been emptied and cleaned, they should be inspected to evaluate their condition. Given the nature of stormwater, the filter bag may become considerably clogged with fine sediment or damaged by various objects in stormwater as well as fauna. Sharp material such as sticks, combined with high velocity water and a large mass in the filter bag, can cause small tears in the filter material. Animals such as rats have also been known to chew through fine mesh filter bags located in gully pits near takeaway food outlets.

3.5.1 Clogged filters

Clogged filter bags can be cleaned using several different methods. If the techniques described in the general maintenance sections above do not adequately clean the filter bags, the following options should be considered:

- Using a stiff brush and a bucket of soapy water, scrub the filter bag surface.
- · Remove filter bags from the pit and wash the bags using a high pressure water spray, taking care not to transfer the contamination elsewhere. Wastewater from the process should be collected and disposed of correctly.
- Remove the filter bags from the pits and the support rings and wash the bags in an industrial washing machine.

This final option typically results in the bags appearing like new, with no visible stain or pore clogging within the filter mesh.



Photo 25 Slightly clogged filter bag, indicated by the brown stain on in the centre of the bag



Photo 26 A clean used filter bag

3.5.2 Damaged filters

Damaged filter bags can often be repaired, provided the damage is small. Small tears in the fabric may occur due to several reasons, however the overall strength and structure of the nylon fabric typically prevents small tears becoming much larger. Although the bag is unlikely to tear further, care must be used when cleaning torn bags so as not to spill the collected material into the pit.

Small tears may be repaired by either sewing the tear back together with additional fabric to increase the strength of the stitching, or by sewing a patch of the filter material onto the filter bag. If large tears are present, the filter bag may need to be replaced as it is no longer able to function as intended.

3.6 Disposal of material

All gully pit wastes are to be taken off site and disposed of at a transfer station or similar approved disposal site. Stormwater sediments can contain lead, copper, zinc, mercury, hydrocarbons and PCBs, which are harmful to both humans and the receiving environment. Appropriate sampling and laboratory analysis may be required to classify the material as suitable for reuse, or disposal under appropriate local guidelines.





Spills and blockages can have an immediate impact on the performance of a stormwater management system, and can potentially result in serious damage to built infrastructure as well as the surrounding waterways and wetlands.

In these types of emergencies, it is important to act quickly to remediate the problem by removing affected sediment or clearing the cause of the blockage, so that the system can resume normal and effective functioning as soon as possible.

4.1 Spill procedures

In the event of a spill discharging into any gully pit, all sediment is to be extracted and the filter bags are to be removed and replaced with rejuvenated filter bags. Normal operation procedures apply to additional cleaning as a result of spills.

4.2 Blockages

In the unlikely event of surface flooding around a gully pit fitted with an EnviroPod the following steps should be carried out:

- Check EnviroPod overflow bypass. The EnviroPod filter has been designed with an overflow mechanism built into the filter box. If surface flooding still exists, check the overflow slots underneath the rubber seal. If debris is lodged in the overflow slots it can be easily cleared by hand or a steel rod.
- If overflow is clear and surface flooding still exists remove EnviroPod and check outlet pipe for blockages.
- Removal of the EnviroPod may be difficult if the filter is clogged and the EnviroPod is holding water. If the filter is clogged, brush the sidewalls of the filter with a yard broom or similar. This will dislodge particles trapped at the interface allowing contained water to flow through the filter.
- If the outlet pipe is blocked, it is likely that a gully sucker truck will be required to unblock it. Debris should be removed from the EnviroPod with the gully sucker truck before removal of the EnviroPod filter. If a gully sucker truck is not available and the EnviroPod needs to be removed by hand, follow the steps below:
- Remove excess debris by hand or brush the side of the filter.
- Lift and place filter ring through the filter box and
- Remove Filter box.
- Lift cage containing filter bag and ring out of the pit.
- Unblock outlet pipe.

The Stormwater Management StormFilter®

For almost two decades the Stormwater Management StormFilter® has helped meet the most stringent stormwater quality requirements.

The system has been continually tested and refined, to ensure it achieves maximum reliability and performance.

As a best management practice (BMP) system, it removes the most challenging target pollutants – including fine solids, soluble heavy metals, oils and total nutrients (including soluble) – by using a variety of media to achieve site-specific pollutant removal objectives.

StormFilter® overview



1.1 Description

StormFilter is a passive, flow-through stormwater filtration system consisting of vaults that house rechargeable cartridges filled with a variety of filter media, and is installed in-line with storm drains. The StormFilter works by passing stormwater through media-filled cartridges, which trap particulates and adsorb materials such as dissolved metals and hydrocarbons. After being filtered through the media, the treated stormwater flows into a collection pipe or discharges into an open channel drainage way. StormFilter is offered in three different configurations: cast-in-place, precast and linear. The precast and linear models utilise pre-manufactured vaults. The cast-in-place units are customised for larger flows and may be either covered or uncovered underground units.

1.2 Operation

1.2.1 Purpose

The StormFilter is a passive stormwater filtration system designed to improve the quality of stormwater runoff from the urban environment before it enters receiving waterways.

Through independent third party studies, it has been demonstrated that the StormFilter is highly effective for treatment of first flush flows, and fast-paced flows, during the latter part of a storm. In general, StormFilter's efficiency is highest when pollutant concentrations are highest. The primary target pollutants for removal are: sediments (TSS), soluble metals, soluble phosphorus, nitrates, and oil and grease.

1.2.2 Sizing

The StormFilter is typically sized to meet design water quality objectives, which are subject to legislation regulated by local government authorities and other relevant environmental bodies. MUSIC modelling software is used to determine pollutant loads from a site, influenced by a number of factors such as site area, imperviousness and land use. Pollutant load reduction capabilities, based on third party testing, allows the number of StormFilter cartridges required to achieve the relevant objectives to be established. Cartridges are designed to treat a peak flow between 0.7 and 1.6 litres/ second, depending on the cartridge size used. For example, 10 standard sized cartridges (460mm) are able to treat 11 L/s, as each filter can treat 1.1 L/s.

Because of the highly porous nature of the granular filter media, the flow through a newly installed cartridge is restricted to 1 L/s (average 460mm), using a restrictor disc, to ensure adequate pollutant-media contact time.



Photo 27 Filter cartridge

1.2.3 Basic function

The StormFilter is designed to siphon stormwater runoff through a filter cartridge containing media. The variety of media available can be designed to act as a mechanical filter to remove sediments, as an ion exchanger to remove dissolved heavy metals, and as an absorber to remove oils and greases.

1.2.4 Priming system function

The treated stormwater collects in the centre tube of the cartridge, which is equipped with a self-priming siphon system. (Figure 1 illustrates this system.) The key component of the system is the plastic float, consisting of a ball located at the base leading up to a larger portion, which provides increased buoyancy. Initially the ball rests in a seat, effectively closing off the port to the drainage manifold.

As a result, the filter fills the centre drainage tube until the water level has risen high enough to purge the air from the filter cartridges and displaces the float. At a water depth of 22 inches the float pulls loose and allows the filtered water to drain out through the manifold. This effectively "primes" a siphon within the drainage tube and greatly increases the potential across the filter. The priming system increases StormFilter's ability to be loaded with sediment. A related feature is the cartridge "hood". This hood maintains the siphon effect by preventing air from being drawn into the cartridge until the external water level drops below the bottom of the hood.

Cartridges are connected to the manifold with a plastic connector. These can be either quarter turn connectors or in the older systems, threaded connectors.

StormFilter is also equipped with flow spreaders that trap floating debris and surface films, even during overflow conditions. Depending on individual site characteristics, some systems are equipped with high and/or low flow bypasses. High flow bypasses are installed when the calculated peak storm event generates a flow that overcomes the overflow capacity of the system. This is especially important for precast systems. Low flow bypasses are sometimes installed to bypass continuous inflows caused by ground water seepage, which usually do not require treatment. All StormFilter units are designed with an overflow. The overflow operates when the inflow rate is greater than the infiltration capacity of the filter media.

1.2.5 Maintenance overview

The primary purpose of the StormFilter is to filter out and prevent pollutants from entering our waterways. Like any effective filtration system, these pollutants must be removed periodically to restore the StormFilter to its full efficiency and effectiveness. Maintenance requirements and frequency are dependent on the pollutant load characteristics of each site. To assist the owner with maintenance issues, Stormwater360 provides detailed Operation and Maintenance Guidelines with each unit.

Stormwater360 can provide maintenance services completely, or in part. Available services include tracking of installed systems, advising the system's owner of maintenance needs, and notification of the regulatory agency once the system has been maintained.

Maintenance is usually performed in the dryer periods to rejuvenate the filter media and prepare the system for the next rainy period. Maintenance activities can also be required in the event of a chemical spill or excessive sediment loading due to site erosion or extreme storms. It is good practice to inspect the system after severe storm events.




Figure 1 Filter cartridge

StormFilter® maintenance and performance expectations



To ensure the optimal and ongoing performance of the StormFilter, the system requires systematic inspection, cleaning and maintenance. This maintenance regime falls into two categories - ongoing minor inspection and maintenance, and major cleaning and maintenance. The maintenance frequency is largely determined by the conditions of each site, and the amount of sedimentation in the stormwater runoff that flows through the system. Unexpected events such as chemical spills, erosion or extreme storm activity require immediate inspection of the system, together with removal of debris or contaminated sediment, and where appropriate, replacement of the media cartridges.

While some maintenance activities can be completed by hand, others require specialised equipment such as an inductor truck with a vacuum hose. In all cases, it is important that maintenance staff are properly trained in the functioning of the StormFilter system and have a good knowledge of the correct procedures for disposing contaminated sediment as well as the methods for removing and installing StormFilter media cartridges.

At all times, appropriate safety equipment must be used, and Occupational Health And Safety (OH&S) guidelines adhered to.

2.1 Types of maintenance

Presently, procedures have been developed for two levels of maintenance:

- Inspection and/or minor maintenance
- Major maintenance.

Inspection/minor maintenance activities are combined since the minor maintenance does not require special equipment and typically little or no materials are in need of disposal.

Inspection/minor maintenance typically involves opening the flow restricting valves (to pre-set levels) and cleaning up vegetation and debris. Major maintenance typically includes cartridge recharging. Major maintenance may involve disposal of materials that require consideration of regulatory guidelines. Depending on the particular unit configuration and equipment used, major maintenance may require an understanding of OSHA rules. Table 1 summarises the primary activities associated with StormFilter maintenance.

Table 1: StormFilter

Facility component requiring maintenance	Maintenance activity	When maintenance activity is required	Expected facility performance after maintaining
StormFilter cartridges and containment structure	Litter and debris removal	Floatable objects or other litter is present in the filter. Remove to avoid hindrance of filtration and eliminate unsightly debris and litter.	Permanent removal from storm system.
StormFilter cartridges and containment structure	Cartridge replacement and sediment removal	Media has been contaminated by high levels of pollutants, such as after a spill.	New media is able to effectively treat stormwater.
Drainage system piping	Flushing with water	Drainage system is obstructed by debris or sediment.	Outflow is not restricted.

2.2 Maintenance activities

2.2.1 Maintenance activity timing

Two scheduled inspections/maintenance activities should take place during the year. During the minor maintenance activities (routine inspection, debris removal), the type of major maintenance required is determined and, if required for disposal, samples of the sediments and media are obtained.

The next scheduled date is to perform major maintenance activities (replacement of the filter cartridges and associated sediment removal). In addition to the scheduled activities, it is important to check the condition of the filter after major storms to check for damage caused by high flows and to check for high sediment accumulation, which may be caused by localised erosion in the drainage area. It may be necessary to adjust maintenance activity scheduling depending on the actual operating conditions encountered by the system.

2.2.2 Maintenance activity frequency

The primary factor controlling timing of maintenance for the StormFilter is sedimentation. A properly functioning system will remove solids from water by trapping these particulates within the porous structure of the media. The flow through the system will naturally decrease as more and more solids are trapped. Eventually the flow through a system will be low enough to require replacement of the cartridges. Sediment should be removed from upstream trapping devices on an as-needed basis to prevent material from being re-suspended and discharged to the system.

Site conditions greatly influence maintenance requirements. StormFilter units located in areas with erosion or active construction should be inspected and maintained more often than those in fully established areas. The maintenance frequency may be adjusted as additional monitoring information becomes available during the inspection program. Areas that develop known problems should be inspected more frequently than areas that demonstrate no problems, particularly after large storms. Ultimately, inspection and maintenance activities should be scheduled based on the historic records and characteristics of an individual filter.

2.3 Maintenance crew requirements

Table 2 lists the anticipated crew requirements for maintenance operations. Removal of water and sediments during major maintenance activities can be accomplished using either a pump and water truck or a vacuum truck. All

applicable occupational health and safety (OH&S) and disposal regulations should be followed. A general description of the maintenance activities follows.

Table 2 Anticipated Crew Requirements

	Inspection/Minor Maintenance	Major Maintenance: Sediment Removal	Major Maintenance: Cartridge Replacement	
Labourer	1		1	
Skilled Worker	1	1	1	
Vacuum/Water Truck Operator		1	0/1	
Total	2*	2*	2/3*	
Special Requirements	Knowledge of Proper StormFilter Function	Knowledge of Disposal Requirements	Knowledge of Cartridge Removal and Installation Procedures	

 $^{^{\}ast}$ May require OH&S trained person if/when vault entry occurs.

2.4 Maintenance methods

2.4.1 Minor maintenance/inspection (twice a year)

Minor maintenance typically will involve the steps below, however if it appears that a spill of some type has occurred, the local hazard control agency and Stormwater360 should be notified immediately.

Steps for Minor Maintenance/Inspection

- Maintenance to be performed by a skilled worker familiar with StormFilter units.
- If applicable, set up safety equipment to protect pedestrians from fall hazards presented by open access covers. Also set up appropriate safety equipment for work near roadways.
- Inspect the external condition of the unit and take notes concerning defects/problems.
- Open the access covers to the vault and allow the system to air out for 5-10 minutes.
- Without entering the vault, inspect the inside of the unit, including components.

- Take notes about the external and internal condition. This includes inspecting pit penetrations, walls, lids, ladders and grates etc.
- Give particular attention to recording the level of sediment build-up on the floor of the vault and on top of the internal components. If flow is occurring, note the level of water and estimate the flow rate per drainage pipe. Record all observations.
- Remove large loose debris and litter using a pole with a grapple or net on the end.
- Close and fasten the access cover, and remove safety equipment.
- Finally, make notes about the local drainage area relative to ongoing construction, erosion problems, or high loadings of other materials to the system.
 - In the case of a spill, workers should abort maintenance activities until the proper guidance has been obtained.

2.4.2 Major maintenance inspection (once a year)

The primary goal of the major maintenance inspection is to assess the condition of the cartridges relative to the level of sediment loading. It may be desirable to conduct this inspection during a storm to observe the relative flow through the filter cartridges. If the submerged cartridges are severely plugged, large amounts of sediments should be present and very little flow will be discharging from the drainage pipes. It is likely that the cartridges need to be replaced. Major maintenance inspection will typically involve the steps below. However, if it appears that a spill of some type has occurred, the local hazard control agency and Stormwater360 should be notified immediately. In the case of a spill, the worker should abort maintenance activities until the proper guidance has been obtained.

Steps for Pre-Major Maintenance Inspection

- Maintenance to be performed by a skilled worker familiar with StormFilter units.
- If applicable, set up safety equipment to protect pedestrians from fall hazards presented by open doors. Also, set up appropriate safety equipment for work near roadways.
- Inspect the external condition of the unit and take notes concerning defects/problems.
- Open the access covers to the vault and allow the vault to air out for 5-10 minutes.
- Without entering the vault, give the inside of the unit, including components, a general condition inspection.
- Take notes about the external and internal condition.
- Give particular attention to recording the level of sediment build-up on the floor of the vault, and on top of the internal components.
- Remove large loose debris and litter using a pole with a grapple or net on the end.
- If the visit is during a storm, make the flow observations discussed above.
- Close and fasten the access cover, and remove safety equipment.
- Make notes about the local drainage area relative to ongoing construction, erosion problems, or high loading of other materials to the system.
- Review the condition reports from the previous minor and major maintenance visits and schedule for cartridge replacement if needed.

2.4.3 Major maintenance: sediment removal and cartridge replacement (and emergency)

Major maintenance/filter cartridge replacement typically involves the steps below. However, if it appears that a spill of some type has occurred, the local hazard control agency and Stormwater360 should be notified immediately. In the case of a spill, the worker should abort maintenance activities until the proper guidance has been obtained.

Depending on the configuration of the particular system, a worker may be required to enter the vault to perform some tasks. If vault entry is required, OH&S rules for general confined space entry must be strictly adhered to. Filter cartridge replacement should occur during dry weather and it may be necessary to plug the filter inlet pipe if base flows exist. Standing water present in the vault should be regarded as polluted and contained during this operation by temporarily capping the manifold connectors.

Please note: Confined space entry may be required on StormFilter systems. In this case, please ensure that appropriate Confined Space entry training and subsequent certification has been undertaken and is valid, and work procedures are strictly adhered to. If you are unsure, do not enter the vault and contact Stormwater360 immediately.

Steps For Cartridge Replacement Maintenance

- Depending on the particular unit, one or two utility workers and a hauling truck operator will deliver the replacement cartridges to the site. Information concerning how to obtain the replacement cartridges is available from Stormwater360.
- If applicable, set up safety equipment to protect pedestrians from fall hazards presented by open doors. Also, set up appropriate safety equipment for work near roadways.
- Inspect the external condition of the unit and take notes concerning defects/problems.
- Open the doors to the vault and allow the system to air out for 5-10 minutes.
- Without entering the vault, give the inside of the unit, including components, a general condition inspection.
- Make notes about the external and internal condition.
- Give particular attention to recording the level of sediment build-up on the floor of the vault and on top of the internal components.
- Ensuring safe working procedures are met, off load the replacement cartridges (16-39kgs each) and set aside.
- Remove the top cap (threaded), upper seal and float from the cartridge. Repeat procedure for every cartridge within StormFilter vault. Place items in a large plastic container to be lifted form the vault.
- Using a cordless drill and 8mm hex head, remove the three screws located around the top perimeter of the cartridge hood. Place screws in the large plastic container and, once full or completed, remove plastic container from vault.
- Move the vacuum truck near the StormFilter vault on the down-wind side. Be sure that the truck is not too close to the vault so that fumes will not enter the vault. Make sure that the last 500mm of the nozzle is approximately 100-125mm in outside diameter.
- Feed vacuum nozzle into cartridge bay and start vacuum truck. Remove cartridge hood and place nozzle directly onto filter media. Completely remove media from each cartridge and repeat process for every cartridge in vault.
- Once completed disconnect cartridges from vault floor and place hood back on cartridges

- Using the appropriate lifting cap, attach the cable and remove the cartridge (up to 10kgs. each) from the vault. It is strictly prohibited to have personnel standing under suspended cartridges. Care must also be used to avoid damaging the cartridges during removal and installation. The cost of repairing components damaged during maintenance will be the responsibility of the owner unless Stormwater360 is performing maintenance activities and damage is not related to discharges to the system.
- Set the used cartridge aside or load onto the hauling truck.
- Repeat steps 14 to 15 until all cartridges have been removed.
- Remove deposited sediment from the floor of the vault. This can be accomplished by using the vacuum truck
- Once the sediments are removed, it is necessary to assess the condition of the vault, particularly the manifold and the connectors. These are short sections of 2-inch schedule 50 PVC, or threaded schedule 80 PVC that should protrude above the floor of the vault. If required, apply a light coating of FDA approved silicon grease to the outside of the exposed portion of the connectors. This ensures a watertight connection between the cartridge and the drainage pipe. Replace any damaged connectors.
- Using the boom, crane, or tripod, lower and install the new cartridges (typically 30kg for standard 460 cartridges). Once again, take care not to damage connectors.
- Close and fasten the access cover, and remove safety equipment.
- Make notes about the local drainage area relative to ongoing construction, erosion problems, or high loadings of other materials to the system.
- Finally, dispose of the residual materials in accordance with applicable regulations. Make arrangements to return the used cartridges to Stormwater360.

2.4.4 Related maintenance activities (performed on an as-needed basis)

StormFilter units are often just one of many components in a more comprehensive stormwater drainage and treatment system. The entire system may include catch basins, detention vaults, sedimentation vaults and manholes, detention/ retention ponds, swales, artificial wetlands, and other miscellaneous components. In order for maintenance of the StormFilter to be successful, it is imperative that all other

components be properly maintained. The maintenance/ repair of upstream facilities should be carried out prior to StormFilter maintenance activities. In addition to considering upstream facilities, it is also important to correct any problems identified in the drainage area. Drainage area concerns may include: erosion problems, heavy oil and grease loading, and discharges of inappropriate materials.

2.5 Typical equipment required for maintenance activities

Typical equipment required for conducting maintenance is shown in Table 3. Some of the materials listed are suggestions rather than requirements. It should be noted that there is more than one way to accomplish some tasks. Owners

with available labour and equipment resources may desire to use alternative methods. However, it is advisable that guidance from Stormwater360 be obtained prior to using alternative techniques.

Table 3 Maintenance Equipment Requirements

Maintenance equipment required

• Safety equipment*: First aid, cones, barricades, flagging, flares, tape, vests, hard hats

- Work clothes: Rubber boots, overalls, and gloves
- Door bolt, wrench, proprietary lifters (e.g. Gatic) and miscellaneous Tools
- Tape measure
- Flashlight
- · Grapple or net pole
- Record keeping forms
- · Litter/debris container

Pre-major maintenance inspection

- Safety equipment*: First aid, cones, barricades, flagging, flares, tape, vests, hard hats
- Work clothes: Rubber boots, overalls, and gloves
- Door bolt, wrench, proprietary lifters (e.g. Gatic) and miscellaneous Tools
- Tape measure
- Flashlight
- Grapple or net pole
- Record keeping forms
- Litter/debris container

- Safety equipment*: First aid, cones, barricades, flagging, flares, tape, vests, hard hats
- Work clothes: Rubber boots, overalls, and gloves
- · Door bolt, wrench, Pentasocket and miscellaneous Tools
- Tape measure
- Flashlight
- Grapple or net pole
- Record keeping forms
- Vacuum truck
- Replacement cartridges
- Cartridge hauling truck
- Crane, tripod and hoist, or other lifting device (150kg minimum capacity)
- Shovels
- Extra 50mm PVC cartridge connectors
- Spare flow restrictor discs
- Litter/debris container
- · Vault inlet pipe plug
- Dolly
- PVC Pipe cutter
- Ladder
- Cartridge installation and removal sling

^{*}Confined space equipment may be required for vault entry. This equipment must be used by personnel with the appropriate OH&S training. This equipment typically includes: Atmospheric testing devices, atmospheric purging and ventilating devices, and entry, exit, and rescue assisting devices.

2.6 Material Disposal

The accumulated sediment found in stormwater treatment and conveyance systems must be handled and disposed of in a manner that will not allow the material to affect surface or ground water. It is possible for sediments to contain measurable concentrations of heavy metals and organic chemicals (such as pesticides and petroleum products). Areas with the greatest potential for high pollutant loading include industrial areas and heavily travelled roads. Sediments and water must be disposed of in accordance with all applicable waste disposal regulations.

It is not appropriate to discharge these materials back to the stormwater drainage system. Part of arranging for maintenance to occur should include coordination of disposal of solids (landfill coordination) and liquids (municipal vacuum truck decant facility, local wastewater treatment plant, on-site treatment and discharge). Owners should contact the local public works department and inquire about how the department disposes of their street waste residuals. Stormwater360 will determine disposal methods or reuse of the media contained in the cartridges. If the material has been contaminated with any unusual substance, the cost of special handling and disposal will be the responsibility of the owner.



SFEP StormFilter & Enviropod Maintenance Data Sheet



Date:	Location:	GPS COORD:				
System size:	Type: O Cast-in-place O Precast C) Linear				
Number of Cartridges:	Type of Cartridge: 0 460mm 0 690m	m 🔾 310mm				
Filter Media: O ZPG O Perlite						
Type of EnviroPods:		Number of EnviroPods:				
Personnel:						
STORMFILTER SYSTEM OBSERVATION	MS					
Last service:	N3					
Sediment Depth on Vault Floor:						
Structural Damage:						
Cartridges submerged: O Yes O No	How deep:					
Comments:						
ENVIROPOD SYSTEM OBSERVATIONS						
Last service:						
Amount of Sediment in Basket:						
Structural Damage:						
Comments:						
DRAINAGE AREA REPORT						
Excessive Oil and Grease Loading (O Yes O No Source:					
Sediment Accumulation on Pavement (O Yes O No Source:					
Erosion of Landscaped Areas (Yes O No Source:					
Comments:						
STORMFILTER CARTRIDGE MAINTENA						
	Yes O No Details:					
	Yes O No Details:					
Quantity of Sediment Removed (estimate?):						
	Yes O No Details:					
	O Yes O No Details:					
Residuals (debris, sediment) Disposal Methods:						
Notes/Problems:						
ENVIROPOD MAINTENANCE ACTIVITIE	ES					
Number of Dage Dagless de	Clogged EnviroPods/Bags: O Yes O 1	No				
Number of Bags Replaced:						

SFEP Treatment Train Inspection Data Sheet



It may be desirable to conduct this inspection during a storm to observe the relative flow through the filter cartridges. If the submerged cartridges are severely plugged, large amounts of sediments should be present, very little flow will be discharging from the drainage pipes, and it is likely that the cartridges need to be replaced during major maintenance.

Date:	Location:	GPS COORD:
System size:	Type: O Cast-in-place O Precast C) Linear
Number of Cartridges:	Type of Cartridge: 0 460mm 0 690m	nm () 310mm
Filter Media: O ZPG O Perlite		
Type of EnviroPods:		Number of EnviroPods:
Personnel Attending Inspection:		
STORMFILTER SYSTEM OBSERVATIO	NC	
Last service:	NO.	
Sediment Depth on Vault Floor:		
Structural Damage:		
Cartridges submerged: O Yes O No	How deep:	
Comments:		
ENVIROPOD SYSTEM OBSERVATIONS Last service:	5	
Amount of Sediment in Basket:		
Structural Damage:		
Comments:		
DRAINAGE AREA REPORT		
Excessive Oil and Grease Loading	○ Yes ○ No Source:	
Sediment Accumulation on Pavement	O Yes O No Source:	
Erosion of Landscaped Areas	○ Yes ○ No Source:	
Comments:		

Next steps

Learn more

For more detailed technical information about Stormwater360 products and solutions, visit www.stormwater360.com.au

Connect with us

With more than 12 years experience in developing, installing and maintaining innovative and efficient site-specific stormwater management solutions, Stormwater360's highly qualified engineers and consultants can assist you with every aspect of your stormwater project.

Whether it's an initial in-house technical presentation, a request to inspect and clean your existing facility, or assistance with designing a specific stormwater management solution for your site, simply complete the enquiry form at stormwater360.com.au or call 1300 354 722 to speak to a Stormwater360 consultant.

Start a project

If you are ready to begin a project, our engineering team will provide you with everything you need, from a free preliminary design to MUSIC modelling, CAD drawings to maintenance frequency and associated costs schedules. To find out more, simply visit www.stormwater360.com.au/custom-solutions and complete the Design Information Request form.




Stormwater360 supplies and maintains a complete range of filtration, hydrodynamic separation, screening and oil/water separation technologies.

Call 1300 354 722





APPENDIX C: COSTIN ROE GENERAL LAYOUT PLAN – SURROUNDING STORMWATER INFRASTRUCTURE






APPENDIX D: ROOTY HILL ROAD UPGRADES PLANS

INTERSECTION AND ROAD WIDENING CABLE PLACE, EASTERN CREEK, NSW CIVIL ENGINEERING WORKS OPTION 1

GENERAL NOTES:

- ALL WORK TO BE CARRIED OUT IN ACCORDANCE WITH BLACKTOWN CITY COUNCIL SPECIFICATION. CONTRACTOR TO OBTAIN AND RETAIN A COPY ON SITE DURING THE COURSE OF THE WORKS.
- 2. ALL NEW WORKS ARE TO MAKE A SMOOTH JUNCTION WITH EXISTING CONDITIONS, AND MARRY IN A 'WORKMANLIKE' MANNER.
- 3. THE CONTRACTOR IS TO VERIFY THE LOCATION OF ALL SERVICES WITH EACH RELEVANT AUTHORITY. ANY DAMAGE TO SERVICES SHALL BE RECTIFIED BY THE CONTRACTOR OR THESE PLANS ARE ONLY THOSE EVIDENT AT THE TIME OF SURVEY OR AS DETERMINED FROM SERVICE DIAGRAMS. HENRY AND HYMAS CONSULTING PTY. LTD. CANNOT GUARANTEE THE INFORMATION SHOWN NOR ACCEPT ANY RESPONSIBILITY FOR INACCURACIES OR INCOMPLETE DATA.
- 4. SERVICES & ACCESSES TO THE EXISTING PROPERTIES ARE TO BE MAINTAINED IN WORKING ORDER AT ALL TIMES DURING CONSTRUCTION.
- 5. ADJUST EXISTING SERVICE COVERS TO SUIT NEW FINISHED LEVELS TO RELEVANT AUTHORITY REQUIREMENTS WHERE NECESSARY.
- 6. REINSTATE AND STABILISE ALL DISTURBED LANDSCAPED AREAS.
- 7. MINIMUM GRADE OF SUBSOIL SHALL BE 0.5% (1:200) FALL TO OUTLETS.
- ALL TEMPORARY SEDIMENT AND EROSION CONTROL DEVICES ARE TO BE CONSTRUCTED. PLACED AND MAINTAINED IN ACCORDANCE WITH THE TECHNICAL SPECIFICATIONS, EROSION AND SEDIMENTATION CONTROL PLAN AND CAMDEN COUNCIL REQUIREMENTS
- 9. CONTRACTOR TO CHECK AND CONFIRM SITE DRAINAGE CONNECTIONS ACROSS THE VERGE PRIOR TO COMMENCEMENT OF SITE DRAINAGE WORKS.
- 10. PROPERTIES AFFECTED BY THE WORKS ARE TO BE NOTIFIED IN ADVANCE WHERE DISRUPTION TO EXISTING ACCESS IS LIKELY.



LOCALITY SKETCH

SIGNAGE AND LINEMARKING NOTES:


- 1. PAVEMENT MARKING AND SIGN POSTING TO BE IN ACCORDANCE WITH RMS "INTERIM GUIDE TO SIGNS AND MARKING."
- RAISED PAVEMENT MARKERS TO BE IN ACCORDANCE WITH RMS "INTERIM GUIDE TO
- 3. WHERE EXISTING PAVEMENT MARKING CONFLICTS WITH PROPOSED, IT IS TO BE
- 4. LANE WIDTHS DO NOT INCLUDE WIDTH OF GUTTER.
- 5. LINEMARKING PLAN DOES NOT DEFINE BOUNDARIES.
- 6. ERECT TEMPORARY SIGN "CHANGED TRAFFIC CONDITIONS AHEAD" 120m AHEAD OF NEW WORK IN BOTH DIRECTIONS.
- 7. ESTABLISH THE LOCATION OF EXISTING UTILITY SERVICES AND LOCATE NEW SIGNS CLEAR OF THESE INSTALLATIONS.
- 8. THE SLOPED FACE OF THE SF MEDIAN KERBS WHICH ADJOIN THROUGH LANES. ARE TO BE PAINTED WHITE IN LIEU OF AN E3 EDGE LINE. THE REFLECTIVE PAVEMENT MARKERS NORMALLY ASSOCIATED WITH AN E3 EDGE LINE ARE TO BE LOCATED ON THE PAVEMENT ADJACENT TO SF KERB.
- 9. THE DESIGN OF MAJOR DIRECTIONAL SIGN POSTING TO BE PREPARED AND ASSESSED BY THE RMS.
- 10. BICYCLE PAVEMENT MARKING AND SIGN POSTING TO BE IN ACCORDANCE WITH

DRAWING SCHEDULE					
15766_C1_C000	COVER SHEET, DRAWING SCHEDULE, NOTES AND LOCALITY SKETCH - OPTION 1				
15766_C1_C100	INTERSECTION LAYOUT - OVERALL PLAN - OPTION 1				
15766_C1_C110					
15766_C1_C120	INTERSECTION LAYOUT - GRADING PLAN , SHEET 1 OF 3				
15766_C1_C121	INTERSECTION LAYOUT - GRADING PLAN , SHEET 2 OF 3				
15766_C1_C122	INTERSECTION LAYOUT - GRADING PLAN , SHEET 3 OF 3				
15766_C1_C240	OPEN CHANNEL PLAN				
15766_C1_C241	OPEN CHANNEL, TYPICAL AND LOGITUDINAL SECTION				
15766_C1_C242	OPEN CHANNEL CROSS SECTIONS				
15766_C1_C250	OVERALL CATCHMENT PLAN				
15766_C1_C251	DETAIL CATCHMENT PLAN, SHEET 1 OF 3				
15766_C1_C252	DETAIL CATCHMENT PLAN, SHEET 2 OF 3				
15766_C1_C253	DETAIL CATCHMENT PLAN, SHEET 3 OF 3				
15766_C1_C601					
15766_C1_C601	INTERSECTION LAYOUT- CONCEPT, -OPTION 1 LINEMARKING PLAN, SHEET 1 OF 3				
15766_C1_C602	INTERSECTION LAYOUT- CONCEPT, LINEMARKING PLAN, SHEET 2 OF 3				
15766_C1_C603	INTERSECTION LAYOUT- CONCEPT, LINEMARKING PLAN, SHEET 3 OF 3				
15766_C1_C650	INTERSECTION LAYOUT - TURNING PATHS, SHEET 1 OF 3 - OPTION 1				
15766_C1_C651	INTERSECTION LAYOUT - TURNING PATHS , SHEET 2 OF 3 - OPTION 1				
15766_C1_C652	INTERSECTION LAYOUT - TURNING PATHS , SHEET 3 OF 3				

RMS REGISTRATION NUMBER

FOR RMS APPROVAL

7												
2											Client	
<u>SURVEY</u>											HANSEN YUNCKEN PTY.LTD.	
INFORMATION											Surveyor	
SURVEYED BY LANDPARTNERS	03	RE-ISSUED FOR RMS APPROVAL	LC	LC	29.08.2016						LANDPARTNERS	
DATUM: AHD	02	RE-ISSUED FOR RMS APPROVAL	LC	LC	13.07.2016						LANDFARTNERS	
ORIGIN OF LEVELS: PM 30122 RL 43.58	01	ISSUED FOR RMS APPROVAL	LC	LC	09.06.2016						This drawing and design remains the property of Henry & Hymas and may not be	
	REVISION	AMENDMENT	DRAWN	DESIGNED	DATE	REVISION	AMENDMENT	DRAWN	DESIGNED	DATE	copied in whole or in part without the prior written approval of Henry & Hymas.	






au om.au	
	henry&hymas


1 loject
INTERSECTION AND ROAD WIDENING
CABLE PLACE, EASTERN CREEK, NSW
Title


tle	[
COVER SHEET, DRAWING SCHEDULE,	
NOTES AND LOCALITY SKETCH - OPTION 1	


Drawn	Designed	Date		
A. ALKATEB	L. CAHA	SEP 2015		
Checked	Approved	Scale		
T. DEMPSEY	A. FRANCIS	N.T.S		
Drawing number			Revision	


15766_C1_C000 | 03




















































LEGEND





301244.928

301240.132

301239.287

301239.043

301236.357

301236.185

301236.602

301237.02

Chainage

4.876

5.582

6.288

15.663

16.075

16.487

16.899

B2-B3

Level

42.703 42.644 42.779 42.790 42.850

KERB R	ETURN No. 03 -	CONTROL LINE	DETAILS - FAC	E OF KERB "SI	KERB"
Pt	Chainage	Easting	Northing	Level	Bearing
A1	0	301250.77	6259519.445	42.578	69°31'46.00"
A2	4.632	301255.109	6259521.065	42.526	69°31'46.00"
A3	6.632	301256.983	6259521.764	42.526	69°31'46.00"
	5	301255.454	6259521.194	42.525	69°31'46.00"
	10	301260.138	6259522.942	42.556	69°31'46.00"
	15	301264.823	6259524.691	42.673	69°31'46.00"
	20	301269.507	6259526.439	42.849	69°31'46.00"
	25	301274.191	6259528.188	42.962	69°31'46.00"
	30	301278.876	6259529.937	42.994	69°31'46.00"
A4	32.573	301281.286	6259530.837	42.979	69°31'46.00"

	KERB RAMP	KR 'A' SETOUT		KERB RAMP	KR 'E'	
Pt	Easting	Northing	Level	Pt	Easting	No
KR A-1	301244.912	6259535.502	42.752	KR E-1	301247.024	62595
KR A-2	301245.255	6259534.964	42.587	KR E-2	301247.515	62595
KR A-3	301247.590	6259533.234	42.509	KR E-3	301249.640	62595
KR A-4	301248.158	6259533.092	42.642	KR E-4	301250.255	62595
KR A-5	301248.434	6259534.091	42.660	KR E-5	301250.060	62595
KR A-6	301246.119	6259535.817	42.740	KR E-6	301247.935	6259

KERB RAMP KR 'B' SETOUT										
Pt	Easting	Northing	Level							
KR B-1	301241.276	6259530.874	42.911							
KR B-2	301241.841	6259530.534	42.751							
KR B-3	301243.816	6259528.428	42.704							
KR B-4	301244.082	6259527.880	42.845							
KR B-5	301243.068	6259527.470	42.850							
KR B-6	301241.093	6259529.578	42.900							

	KERB RAMP KR 'F' SETOUT									
Pt	Easting	Northing	Level							
KR F-1	301247.011	6259505.848	42.891							
KR F-2	301246.983	6259505.238	42.737							
KR F-3	301247.582	6259502.912	42.721							
KR F-4	301247.905	6259502.378	42.866							
KR F-5	301248.731	6259503.262	42.820							
KR F-6	301248.131	6259505.589	42.840							

KERB RAMP KR 'G' SETOUT

Northing

6259506.697

6259506.135

6259504.429

6259504.105

6259505.220

6259500.411

6259500.424

6259502.345

Level

42.688

42.552

42.607

42.771

42.760

42.562

42.550

42.480

Easting

301252.732

301252.479

301250.984

301250.461

301250.082

301255.465

301256.623

301257.830

Pt

KR G-1

KR G-2

KR G-3

KR G-5

KR H-5

	KERB RAMP	KR 'C' SETOUT	
Pt	Easting	Northing	Level
KR C-1	301238.163	6259529.287	43.001
KR C-2	301238.158	6259528.676	42.849
KR C-3	301238.846	6259526.375	42.837
KR C-4	301239.189	6259525.854	42.984
KR C-5	301239.980	6259526.769	42.940
KR C-6	301239.292	6259529.071	42.950

KERB RAMP KR 'D' SETOUT

301240.934

301241.541

301243.807

301244.409

301243.381

301241.114

6259525.341

6259525.269

6259525.683

6259525.976

6259526.825

6259526.411

KR D-1

KR D-5

KR D-6

Level

42.947

42.781

42.720

42.853

42.860

42.920

	KR G-6	301251.577	6259506.926	42.700
1				
		KERB RAMP I	KR 'H' SETOUT	
	Pt	Easting	Northing	Level
	KR H-1	301257.300	6259503.342	42.469
	KR H-2	301256.820	6259502.992	42.335
	KR H-3	301255.606	6259501.060	42.396

B6	17.311	301237.357	6259535.319	42.857	136°51'14.57"			
В7	28.865	301245.258	6259526.889	42.67	136°51'14.57"			
B7-B8	29.187	301245.502	6259526.629	42.675		0.6	0.643	61°23'27.30"
B8	29.508	301245.39	6259526.291	42.68	198°14'41.86"			
B8-B1	29.83	301245.279	6259525.952	42.685		0.6	0.643	61°23'27.30"
B1	30.151	301244.928	6259525.888	42.69	259°38'09.16"			
		KERB RETURN	No. 05 - CONTR	OL LINE DETA	ILS - FACE OF K	KERB "SM K	ERB"	
		KERB RETURN	No. 05 - CONTR	OL LINE DETA	ILS - FACE OF K	(ERB "SMK	ERB"	
				1		1	<u> </u>	
Pt	Chainage	Easting	Northing	Level	Bearing	Rad/Spiral	A.Length	D.Angle
Pt C1	Chainage 0	Easting 301247.911	Northing 6259501.634			1	A.Length	D.Angle
C1				42.830		1	A.Length 0.325	D.Angle 62°09'49.49"
C1	0	301247.911	6259501.634	42.830		Rad/Spiral		
C1 C1-C2 C2	0 0.163	301247.911 301247.956	6259501.634 6259501.459	42.830 42.825 42.82	Bearing	Rad/Spiral		
C1 C1-C2 C2	0 0.163 0.325	301247.911 301247.956 301248.132	6259501.634 6259501.459 6259501.417	42.830 42.825 42.82 42.815	Bearing	Rad/Spiral	0.325	62°09'49.49"
C1 C1-C2 C2 C2-C3	0 0.163 0.325 0.488	301247.911 301247.956 301248.132 301248.308	6259501.634 6259501.459 6259501.417 6259501.375	42.830 42.825 42.82 42.815	Bearing 103°23'38.78"	Rad/Spiral	0.325	62°09'49.49"

KERB RETURN No. 04 - CONTROL LINE DETAILS - FACE OF KERB "SM KERB"

42.69

42.819

42.826

42.833

42.88

42.874

42.869

42.863

343°21'07.86"

58°10'40.85"

Northing

6259525.888

6259525.011

6259524.899

6259525.716

6259534.698

6259535.159

6259535.418

6259535.678

Rad/Spiral A.Length

0.6

0.6

1.412 80°52'53.10"


78°40'33.72"

78°40'33.72"


0.824


0.824

Pt	Chainage	Easting	Northing	Level	Bearing	Rad/Spiral	A.Length	D.Angle
C1	0	301247.911	6259501.634	42.830				
C1-C2	0.163	301247.956	6259501.459	42.825		-0.3	0.325	62°09'49.49"
C2	0.325	301248.132	6259501.417	42.82	103°23'38.78"			
C2-C3	0.488	301248.308	6259501.375	42.815		-0.3	0.325	62°09'49.49"
C3	0.651	301248.427	6259501.511	42.81	41°13'49.29"			
C4	14.661	301257.661	6259512.047	42.44	41°13'49.29"			
C4-C5	14.992	301257.917	6259512.34	42.442		-0.5	0.662	75°51'01.65"
C5	15.323	301257.696	6259512.661	42.445	325°22'47.65"			
C5-C6	15.654	301257.475	6259512.982	42.447		-0.5	0.662	75°51'01.65"
C6	15.985	301257.11	6259512.845	42.45	249°31'46.00"			
C7	26.854	301246.927	6259509.044	42.77	249°31'46.00"			
C7-C8	27.587	301246.083	6259508.729	42.785		-1	1.466	83°58'17.73"
C8	28.32	301246.308	6259507.858	42.8	165°33'28.27"			
C1	34	301247.911	6259501.634	42.830				



KERB RAMP SETOUT DETAIL SCALE N.T.S.





LONGITUDINAL SECTION KERB RETURN No.03 - FACE OF KERB HORIZONTAL SCALE 1:250 @ A1 VERTICAL SCALE 1:50 @ A1





FOR RMS APPROVAL


RMS REGISTRATION NUMBER:


SCALE 1:250

										CI	Client				Project	Drawn	Designed Date	
SURVEY										\square \lor	WESTERN SYDNEY PARKLANDS TRUST	Level 5, 79 Victoria Avenue	Telephone e +61 2 9417 8400		INTERSECTION AND ROAD WIDENING	L. CAHA	L. CAHA SEF	P 2015
												Chatswood NSW 20	067 Facsimile		CARLE DI ACE EACTERNI OREEK NOW	Checked	Approved Scale	е
<u>INFORMATION</u>										St	Surveyor	- nemen/	+61 2 9417 8337		CABLE PLACE, EASTERN CREEK, NSW	T. DEMPSEY	A. FRANCIS AS	SHOWN @ A1
SURVEYED BY LANDPARTNERS										i	LANDPARTNERS	E S S S S S S S S S S S S S S S S S S S	Email email@hhconsult.com.au		Title	Drawing number		Revision
DATUM: AHD													Web		SETOUT DETAILS AND SECTION	45700		2 2 4
ORIGIN OF LEVELS: PM 30122 RL 43.58	01 ISSUE FOR REVIEW		LC	LC	30.06.2017						This drawing and design remains the property of Henry & Hymas and may not be	Global-Mark.com.au®	www.henryandhymas.com.alp	enrythyma		15766_	C1 C153	3 ()1 ⁻
	REVISION	AMENDMENT	DRAWN	DESIGNED	D DATE REVIS	SION	AMENDMENT	DRAWN	DESIGNED DA	ATE	copied in whole or in part without the prior written approval of Henry & Hymas.		1	en your yn i da	KERB RETURN No.03, 04 & 05		_	









Pt	Chainage	Easting	Northing	Level	Bearing	Rad/Spiral	A.Length	D.Angle
A1	0	301283.699	6259524.373	42.825	249°31'49.02"			
A1-A2	6.86	301277.209	6259521.951	42.817		-40.5	13.721	19°24'38.6
	10	301274.855	6259519.761	42.762	235°22'59.44"			
A2	13.721	301271.894	6259517.51	42.655				
	20	301267.075	6259513.483	42.415	230°07'09.79"			
A3	25.283	301263.021	6259510.096	42.289				
A3-A4	27.731	301261.14	6259508.524	42.273		-40.5	4.897	6°55'39.90
	30	301259.586	6259506.868	42.281	223°26'45.34"			
A4	30.18	301259.462	6259506.737	42.283				
A5	31.392	301258.606	6259505.879	42.298	224°56'21.41"			
	40	301253.963	6259498.705	42.5	200°52'50.97"			
A5-A6	43.105	301249.296	6259496.549	42.555		-20.5	23.427	65°28'31.8
	50	301252.773	6259488.876	42.621	172°55'54.00"			
A6	54.819	301253.92	6259484.207	42.622				
	60	301255.737	6259479.355	42.604	159°27'48.81"			
	70	301259.245	6259469.991	42.569	159°27'48.81"			
	80	301262.754	6259460.626	42.566	159°27'48.81"			
	90	301266.262	6259451.262	42.601	159°27'48.81"			
	100	301269.77	6259441.897	42.637	159°27'48.81"			
	110	301273.278	6259432.533	42.672	159°27'48.81"			
	120	301276.786	6259423.168	42.707	159°27'48.81"			
	130	301280.294	6259413.804	42.743	159°27'48.81"			
	140	301283.802	6259404.439	42.778	159°27'48.81"			
	150	301287.31	6259395.075	42.813	159°27'48.81"			
A7	153.736	301288.62	6259391.576	42.827	159°27'48.81"			

Pt	Chainage	Easting	Northing	Level	Bearing	Rad/Spiral	A.Length	D.Angle
B1	0	301288.62	6259391.576	42.827	159°27'48.81"			
	10	301292.245	6259382.256	42.874	158°01'58.63"			
B1-B2	15.779	301294.158	6259376.793	42.901		-400.5	31.557	4°30'52.57"
	20	301296.101	6259373.03	42.92	156°36'08.45"			
	30	301300.186	6259363.903	42.967	155°10'18.27"			
B2	31.557	301300.843	6259362.491	42.975				
B2-B3	39.419	301304.179	6259355.354	43.012		-100.499	15.723	8°57'49.82"
	40	301304.735	6259355.001	43.014	150°08'08.25"			
В3	47.28	301308.585	6259348.825	43.049				
	50	301310.076	6259346.55	43.061	147°33'04.71"			
B3-B4	59.048	301315.199	6259339.024	43.104		99.5	23.536	13°33'11.23"
	60	301315.008	6259337.856	43.108	153°18'34.84"			
	70	301319.044	6259328.711	43.155	159°04'04.97"			
B4	70.817	301319.333	6259327.947	43.159	159°32'17.74"			
	80	301322.543	6259319.343	43.202	159°32'17.74"			
	90	301326.039	6259309.974	43.249	159°32'17.74"			
	100	301329.535	6259300.605	43.296	159°32'17.74"			
	110	301333.03	6259291.236	43.335	159°32'17.74"			
	120	301336.526	6259281.867	43.351	159°32'17.74"			
	130	301340.022	6259272.498	43.344	159°32'17.74"			
	140	301343.518	6259263.129	43.313	159°32'17.74"			
	150	301347.014	6259253.76	43.268	159°32'17.74"			
	160	301350.51	6259244.39	43.222	159°32'17.74"			
	170	301354.005	6259235.021	43.176	159°32'17.74"			
	180	301357.501	6259225.652	43.095	159°32'17.74"			
	190	301360.997	6259216.283	43.012	159°32'17.74"			
B5	199.786	301364.418	6259207.115	42.982	159°32'17.74"			
	200	301364.494	6259206.915	42.982	158°44'50.89"			
B5-B6	207.367	301367.302	6259199.386	43.02		-15.5	15.161	56°02'35.47'
	210	301370.776	6259199.357	43.023	121°46'56.82"			
В6	214.947	301375.323	6259197.461	42.995	103°29'42.27"			

	0	1000	2000	3000	4000	5000mm
1000 600 200			SCALE 1:50)		
	0	5	10	15	20	25m
5 4 3 2 1		Ş	SCALE 1:25	0		

RMS REGISTRATION NUMBER:

FOR RMS APPROVAL

											Client		$\overline{}$
SURVEY											WESTERN SYDNEY PARKLANDS TRUST	Level 5, 79 Victoria Avenue	Telepho
INFORMATION											Surveyor	Chatswood NSW 2067	7 Facsim +61 2
SURVEYED BY LANDPARTNERS											LANDPARTNERS	S & S	Email email@
DATUM: AHD											LANDI ANTINCINO		Web www.h
ORIGIN OF LEVELS: PM 30122 RL 43.58	01	ISSUE FOR REVIEW		LC	LC	30.06.2017					This drawing and design remains the property of Henry & Hymas and may not be	Global-Mark.com.au®	www.ii
	REVISION		AMENDMENT	DRAWN	DESIGNED	DATE	REVISION	AMENDMENT DRAWN	DESIGNED	DATE	copied in whole or in part without the prior written approval of Henry & Hymas.		

Telephone
+61 2 9417 8400

Facsimile
+61 2 9417 8337


Email
email@hhconsult.com.au
Web
www.henryandhymas.com.au


om.au	
Jiii.dµ	henr & hymas


Project
INTERSECTION AND ROAD WIDENING CABLE PLACE, EASTERN CREEK, NSW
CABLE PLACE, EASTERN CREEK, NSW
Title
SETOUT TABLES AND SECTION

KERB RETURN No.06 & No.07

15766	C1 C1	56	∩1
Drawing number			Revision
T. DEMPSEY	A. FRANCIS	AS SHO\	NN @ A1
Checked	Approved	Scale	
L. CAHA	L. CAHA	SEP 201	5
Drawn	Designed	Date	







LEGEND

— - - — - - — EXISTING BOUNDARY

	KERB RETURN No. xx - CONTROL LINE DETAILS - LIP OF KERB													
Pt Chainage		Easting	Northing	Level	Bearing	Rad/Spiral	A.Length	D.Angle						
A1	0	301377.488	6259161.852	43.237	284°37'47.50"									
A1-A2	1.559	301375.018	6259162.497	43.248		-1.5	3.119	119°07'40.87"						
A2	3.119	301375.657	6259160.025	43.258	165°30'06.64"									
MJ	5	301376.124	6259158.202	43.271	165°45'59.33"									
MJ	10	301377.324	6259153.349	43.304	166°28'11.43"									
MJ	15	301378.464	6259148.48	43.337	167°10'23.53"									
MJ	20	301379.544	6259143.598	43.385	167°52'35.63"									
A2-A3	21.86	301380.353	6259141.867	43.405		407.3	37.483	5°16'22.17"						
MJ	25	301380.564	6259138.703	43.44	168°34'47.73"									
MJ	30	301381.524	6259133.797	43.495	169°16'59.83"									
MJ	35	301382.423	6259128.878	43.55	169°59'11.93"									
MJ	40	301383.262	6259123.949	43.606	170°41'24.03"									
A3	40.602	301383.359	6259123.355	43.612	170°46'28.81"									
A3-A4	41.493	301383.579	6259122.001	43.619		-0.9	1.782	113°27'10.69"						
A4	42.384	301384.734	6259122.742	43.625	57°19'18.12"									

KERB RAMP KR 'A' SETOUT											
Pt Easting Northing Level											
KR A-1	301381.551	6259160.043	43.260								
KR A-2	301380.918	6259160.464	43.146								
KR A-3	301377.388	6259161.441	43.211								
KR A-4	301376.769	6259161.164	43.354								
KR A-5	301377.535	6259160.123	43.340								
KR A-6	301381.064	6259159.141	43.270								


NOSE OF MEDIAN SETOUT											
Pt	Easting	Level									
B1	301379.533	6259183.455	43.279								
B2	301379.054	6259182.142	43.329								
C1	301332.002	6259189.681	43.888								
C2	301331.698	6259187.818	43.900								


KERB RAMP KR 'A' SETOUT											
Pt	Level										
KR B-1	301376.424	6259160.850	43.360								
KR B-2	301376.116	6259160.288	43.217								
KR B-3	301376.892	6259157.200	43.238								
KR B-4	301377.216	6259156.648	43.393								
KR B-5	301378.160	6259157.079	43.360								
KR B-6	301377.376	6259160.167	43.340								


RMS REGISTRATION NUMBER:


FOR RMS APPROVAL


												1			
							Client				Project	Drawn	Designed	Date	
<u>SURVEY</u>							WESTERN SYDNEY PARKLANDS TRUST	Level 5, 79 Victoria Avenue	Telephone +61 2 9417 8400		INTERSECTION AND ROAD WIDENING	L. CAHA	L. CAHA	SEP 2015	
							TWEOTERN OTBINET TANKER INDO TROOT	Chatswood NSW 206	Facsimile +61 2 9417 8337			Checked	Approved	Scale	
<u>INFORMATION</u>							Surveyor	_agemen/	+61 2 9417 8337		CABLE PLACE, EASTERN CREEK, NSW	T. DEMPSEY	A. FRANCIS	AS SHOWN @	∮ A1
SURVEYED BY LANDPARTNERS							LANDPARTNERS	S &	Email email@hhconsult.com.au		Title	Drawing number		Revision	sion
DATUM: AHD							LANDI AKTINEKO	° W	Web "		SETOUT DETAILS AND SECTION	145700	04 0	4 F O 4	~ 4
ORIGIN OF LEVELS: PM 30122 RL 43.58	01	ISSUE FOR REVIEW	LC LC 30.06.2017				This drawing and design remains the property of Henry & Hymas and may not be	Global-Mark.com.au®	www.henryandhymas.com.alj	honrythymae		15766		158 (.)1
	REVISION	AMENDMENT	DRAWN DESIGNED DATE	REVISION	AMENDMENT	DRAWN DESIGNED DATE	copied in whole or in part without the prior written approval of Henry & Hymas.			Herri Maryrius	KERB RETURN No.09			•	•











SCALE 1:250

LONGITUDINAL SECTION - OPEN CHANNEL - BASE OF CHANNEL

HORIZONTAL SCALE 1:250 @ A1

VERTICAL SCALE 1:50 @ A1

RMS REGISTRATION NUMBER:

FOR RMS APPROVAL

SURVEY							HANSEN YUNCKEN PTY.LTD.	Level 5, 79 Victoria Avenue	Telephone +61 2 9417 8400	INTERSECTION AND ROAD WIDENING	Drawn L. CAHA	Designed L. CAHA	SEP 2015
INFORMATION SURVEYED BY LANDPARTNERS							Surveyor LANDPARTNERS	Chatswood NSW 206	Facsimile +61 2 9417 8337 Email email@hhconsult.com.au	CABLE PLACE, EASTERN CREEK, NSW	T. DEMPSEY Drawing number	A. FRANCIS	AS SHOWN @ A1
DATUM: AHD ORIGIN OF LEVELS: PM 30122 RL 43.58	01 REVISION	ISSUED FOR RMS APPROVAL AMENDMENT	LC DRAWN DE	LC XX.0X.2017 SIGNED DATE REVISION	AMENDMENT	DRAWN DESIGNED DATE	This drawing and design remains the property of Henry & Hymas and may not be copied in whole or in part without the prior written approval of Henry & Hymas.	Global-Mark.com.au®	Web www.henryandhymas.com.au heni	OPEN CHANNEL TYPICAL AND LOGITUDINAL SECTION	15766	6_C1_C2	241 01



